

MD-23 INSTALLATION



INSTALLATION INSTRUCTIONS

Retractable Pull Out Garment Rod Installation

1. Drill a 3/4" diameter hole through the wall with wood backing or wood framing.
2. Remove Knob, cover rose and Rod from the Housing with Mounting Flange. Insert Housing with Flange into hole in the wall and mark screw locations on the wall.
3. Remove Housing from the wall and pilot drill at locations. Slip housing onto the rod so the housing end without flange is up against the small cap on the end of the rod. Slip housing into the hole in the wall being careful not to let the rod fall into the wall. Screw flange to the wall.
4. Screw Cover Rose on the mounting Flange, Screw Knob Tip on the Rod.

