## P-470-22-DWS




LLIED /SRASS

INC

Step 1: Drill holes in Wall for screw anchors and Mount with Screws provided.

Determine your desired location for installation. Mark each wall flange screw location to be drilled. Drill hole at each of the marks. Place anchors into the holes made. Then mount and secure unit into mounting surface using screws provided.



No portion of this document or any artwork contained herein should reproduced in any way without the written conset of ALLIED BRASS INC.