ASSEMBLY INSTRUCTION

ITEM:White Pine-Chest

NO	PART LIST	QTY	STEP 1 Begin assembly by screwing wooden legs (2) to the bottom side of Cabinet(1).	STEP 2 Assembly Complete.
1	THREE DRAWERS CABINET	1PC		
2	WOODEN LEG WITH SCREW	4PCS		