


## **ASSEMBLY INSTRUCTIONS**

BS1130CW / BS1132CW / BS1136CW / BS1142CW BS1148CW / BS1160CW / BS1172CW BS1030VW / BS1032VW / BS1036VW / BS1040VW BS1042VW / BS1048VW







Rags

- 1.Position the backsplash on top of the vanity and flush against the finished wall.
- 2. Verify the sides of the backsplash are aligned with the sides of the vanity top.
- 3. Secure the backsplash using a bead of siliconized acrylic caulk on the back surface.
- 4. Apply a bead of caulk along the seam of the wall and backsplash.
  Clean and remove any excess caulk.

