




# **Installation Manual For 145.2410**

# 3-Hole Deck Mount Roman Tub Filler



#### **NOTICE TO HOMEOWNER**

- We recommend that this product is installed by a qualified professional plumber.
- Please check this product immediately to ensure that it has not been damaged and is complete. Before installation, please make sure this product is the correct model and you have all the parts required for installation and use.
- Please flush the water system to ensure that no metal swarf, solder, and other imputities can enter the product.
- Turn off water supply before commencing work.
- Please read these instructions carefully and retain for future reference.

#### **BEFORE YOU BEGIN**

- You must observe all local plumbing laws and codes.
- Do not instal valve if it does not meet local plumbing codes.
- Shut off the main water supply.





# **Installation Manual For 145.2410**

# 3-Hole Deck Mount Roman Tub Filler

# **TABLE OF CONTENTS**

| OPERATING SI | PECIFICATION: | 5.  |     |     |  |  |  |  |  |  | 3 |
|--------------|---------------|-----|-----|-----|--|--|--|--|--|--|---|
| INSTALLING T | HE HOT & COL  | D H | AND | LES |  |  |  |  |  |  | 4 |
| INSTALLING T | HE TUB SPOUT  | Γ.  |     |     |  |  |  |  |  |  | 7 |
| INSTALLING T | HE HOSES .    |     |     |     |  |  |  |  |  |  | 8 |





#### **OPERATING SPECIFICATIONS**

## **WATER TEMPERATURE**



This product is to be used with water at a temperature range of 40°F - 120°F ONLY!

# **WATER PRESSURE**




This product is to be used with a water pressure range of 15 PSI to 80 PSI ONLY

If water pressure is greater than 80 PSI, install a pressure reducer valve (PRV)


This valve meets or exceeds ANSI A112.18.1 and ASSE 1016




#### **INSTALLING THE HOT & COLD HANDLES**




Install nut and washers onto valve



Insert valve into 1.20" hole from below the deck




Install trim ring and twist to tighten




Install handle riser




## **INSTALLING THE HOT & COLD HANDLES**




Install body from top of deck






Install plastic spacer




Install screw & washer and tighten




## **INSTALLING THE HOT & COLD HANDLES**



Remove set-screw and install handle




Tighten set-screw




Twist to verify smooth operation




#### **INSTALLING THE TUB SPOUT**




The spout is seen above



Insert spout into deck hole, then insert washers and tighten retaining nut & T-fitting




Remove T-fitting








## **INSTALLING THE HOSES**



Connect Hot-side connection



Connect Cold-side connection