



Rough-In Measurements*

Left-Hand Drain:

SM-AB541 : 10 ⁵/₈"

SM-AB543 : 10 ⁵/₈"

SM-AB545 : 9 ⁷/₈"

SM-AB549 : 7 ⁷/₈"

SM-AB552 : 8 ¹/₄"

SM-AB561 : 9 ⁷/₁₆"

SM-AB570 : 10 ⁵/₈"

SM-AB580 : 10 ⁵/₈"

Right-Hand Drain

SM-AB540 : 10 ⁵/₈"

SM-AB542 : 10 ⁵/₈"

SM-AB546 : 9 ⁷/₈"

SM-AB550 : 7 ⁷/₈"

SM-AB551 : 8 ¹/₄"

SM-AB560 : 9 ⁷/₁₆"

SM-AB571 : 10 ⁵/₈"

SM-AB581 : 10 ⁵/₈"

* The provided dimensions list the location of the drain hole for your Swiss Madison bathtub. This is not a substitute for a certified plumber rough-in installation. It is provided as supplemental information only.