


# Premium Aluminum Single Monitor Wall Mount

Instruction Manual



# SKU: MOUNT-G100B



Scan the QR code with your mobile device or follow the link for helpful videos and specifications related to this product.

https://vivo-us.com/products/mount-g100b

GET IN TOUCH | Monday-Friday from 7:00am-7:00pm CST







309-278-5303


# ♠ WARNING!

If you do not understand these directions, or if you have any doubts about the safety of the installation, please call a qualified technician. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.



## **WARNING: CHOKING HAZARD**

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.



NOTE: SOME HARDWARE INCLUDED MAY NOT BE USED



### A CAUTION!

DO NOT INSTALL INTO DRYWALL ALONE. VERIFY YOUR WALL CONSTRUCTION. USE WOOD STUDS TO MOUNT. We include mounting for brick and concrete walls. If unsure, please contact us at vivo-us. com, email at help@vivo-us.com, or call us at 309-278-5303.

#### TOOLS NEEDED





DO NOT EXCEED WEIGHT CAPACITY. Failure to do so may result in serious injury.






## **ASSEMBLY STEPS**

#### STEP 1


#### **OPTION A: Wood Wall**


Using the wall plate on the arm (A), mark drilling locations. Use of a stud finder is highly recommended. Drill 2.2" (55mm) deep holes using a 3/16" (4.5mm) drill bit, and mount the arm to the wall using screws (W-A) and washers (W-C).



XX







#### OPTION B: Concrete/Brick Wall


Using the wall plate on the arm (A), mark drilling locations. Drill 2.4" (60mm) deep holes using a 3/8" (10mm) drill bit, press anchors (W-B) into holes, and mount the arm to the wall using screws (W-A) and washers (W-C). NOTE: Anchors are made for use with concrete or brick, and will not work with drywall.
















## STEP 2




## STEP 3





Adjust gas spring tension using the Allen wrench **(C)**. Turn counter-clockwise to increase lift, and clockwise to decrease. Adjust the tilt joint support using the Allen key. **NOTE:** use a large flat-blade screwdriver to tighten the socket set screw if the joint makes a popping noise.













## Open Monday - Friday 7:00am - 7:00pm CST,

our dedicated support team can offer immediate assistance with rapid response times. If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.

 $\subseteq$ 

help@vivo-us.com

AVG. RESPONSE TIME (within office hrs): 1HR 8M

- 23% within < 15m
- 38% within < 30m
- 61% within < 1hr
- 83% within < 2hr
- 92% within < 3hr



www.vivo-us.com
Chat live with an agent!

AVG. RESOLUTION TIME (within office hrs): < 15 M



309-278-5303

AVG. RESOLUTION TIME (within office hrs): 5M 4S