# **Cabinet**




**ASSEMBLY INSTRUCTION** 

# HARDWARE LIST


A 10 PCS	B 10 PCS	C 8 PCS		D 8 PCS	<b>Designation</b>	E 2 PCS	
F 4 PCS	G 4 PCS	H 24 PCS	Managar	I 6 PCS	97	J 8 PCS	Aming.
K 8 PCS	L 1 PC	M 2 PCS		N 2 PCS		O 2 PCS	
P 2 PCS	Q 4 PCS	R 4 PCS	A Ding				


# PARTS LIST



#### STEP 1.


Fix parts 11 and 12 to parts 10 using screws (I) and allen key (L), as shown





#### STEP 2.

Fix magnetic door catches (E) to parts 1 and 3 using screws (R), as shown. Fix wall straps (N) to part 1 and 3 using washers (M) and screws (M), as shown.













#### STEP 3.


Fix hinges (F) to doors 8 and 9 using screws (H), as shown. Fix handles (O) and door catch plates (Q) to doors 8 and 9 using screws (J), as shown.






#### STEP 4.


Insert quickfit screws (A) into parts 4 and 5, as shown. Insert cam locks (B) into parts 6 and 13, as shown. Fit parts 6 and 13 to parts 4 and 5. Turn cam locks clockwise to tighten.






#### STEP 5.


Attach part 3 to parts 4 and 5 with wooden dowels (C) and screws (D), as shown.





#### STEP 6.


Slide part 7 into grooves between parts 4, 3 and 5, as shown.



#### STEP 7.

Insert quickfit screws (A) and wooden dowels (C) into part 1, as shown. Insert cam locks (B) into parts 4 and 5, as shown.

Fit part 1 to assembled unit. Turn cam locks clockwise to tighten.










## STEP 8.

Fix metal legs to part 3 using screws (K), as shown. Secure part 13 to part 1 using screws (D), as shown.








#### STEP 9.


Fix doors 8 and 9 to assembled unit with hinges and screws (H), as shown.



#### **STEP 10.**


Fit shelf supporters (G) to the inside of cabinet, as shown. Place shelf 2 on top of shelf supporters, as shown.






#### **STEP 11.**

For extra stability, you must fix your Cabinet to the wall using hardwares (D, M and P), as shown. Screws (D) are fixed through washers (M) and wall straps and into the wall plugs (P). Should you choose not to affix the product to the wall, serious injury may be caused if the product tips over.





#### **STEP 12.**

