ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.


3. Keep all hardware parts out of reach of children.


NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.


Tool needed: Screwdriver & Rubber Mallet (not provider).


	PART LIST	
ITEM	DESCRIPTION	QTY
Α	CUSHION BACK	1 PC
В	CUSHION SEAT	1 PC
C	LEG SUPPORT FRONT	1 PC
D	LEG SUPPORT BACK	1 PC
Е	LEG LEFT	1 PC
F	LEG RIGHT	1 PC
G	ARM	1 PC

HARDWARE LIST			
ITEM	DESCRIPTION		QTY
1	JCBC Bolt M6 x 50mm	@	4pcs
2	JCBB Bolt M8 x 45mm	@	8pcs
3	M8 FLAT WASHER	0	8pcs
4	M6 SPRING WASHER		4pcs
5	M8 SPRING WASHER		8pcs
6	WOOD SCREW M4 x 38mm		10PCS
7	M4 ALLEN KEY (BALL SHAPE)		1PC
8	M5 ALLEN KEY (BALL SHAPE)		1PC
9	WOOD DOWEL M8 x 30mm		8PCS









ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.


- CAUTIONS: 1. Do not FULLY TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.
 - 2. Do not OVER TIGHTEN the nut or bolt to avoid causing damages to the thread.
 - 3. Keep all hardware parts out of reach of children.


NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.


Tool needed: Screwdriver & Rubber Mallet (not provider).


PART LIST		
ITEM	DESCRIPTION	QTY
Α	CUSHION BACK	1 PC
В	CUSHION SEAT	1 PC
С	LEG SUPPORT FRONT	1 PC
D	LEG SUPPORT BACK	1 PC
Е	LEG LEFT	1 PC
F	LEG RIGHT	1 PC

HARDWARE LIST			
ITEM	DESCRIPTION		QTY
1	JCBC Bolt M6 x 50mm	~~~~~~	4pcs
2	JCBB Bolt M8 x 45mm	@	6pcs
3	M8 FLAT WASHER	0	6pcs
4	M6 SPRING WASHER		4pcs
5	M8 SPRING WASHER		6pcs
6	WOOD SCREW M4 x 38mm	••••••••••••••••••••••••••••••••••••••	10PCS
7	M4 ALLEN KEY (BALL SHAPE)		1PC
8	M5 ALLEN KEY (BALL SHAPE		1PC
9	WOOD DOWEL M8 x 30mm		8PCS









ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

	PART LIST	
ITEM	DESCRIPTION	QTY
Α	TABLE TOP	1 PC
В	LEGS	4 PCS

	PART LIST		
ITEM	DESCRIPTION		QTY
1	JCBC BOLT M6 x 60mm	ammac -(-)	8 PCS
2	M6 FLAT WASHER	0	8 PCS
3	M6 SPRING WASHER		8 PCS
4	M4 ALLEN KEY	<u> </u>	1 PC

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

