MODEL : BBT 8054 - SF

ASSEMBLY INSTRUCTIONS


1 OF 2


Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS : 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed. 2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread. 3. Keep all hardware parts out of reach of children.

NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

PART LIST			HARDWARE LIST			
ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY	
A	CHAIR	1 PC	1	JCBB Bolt M8 x 45mm	8 PCS	
В	LEG FRONT	2 PCS	2	M8 FLAT WASHER 💿	8 PCS	
C	LEG BACK	2 PCS	3	M8 SPRING WASHER C	8 PCS	
			4	M5 ALLEN KEY (BALL SHAPE)	1 PC	





2 OF 2

MODEL : BBT 8054 - SF

ASSEMBLY INSTRUCTIONS


Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched.


Follow the figure to start assembling.

CAUTIONS : 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed. 2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread. 3. Keep all hardware parts out of reach of children.

NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

PART LIST			HARDWARE LIST			
ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY	
Α	BENCH	1 PC	1	JCBB Bolt M8 x 45mm	8 PCS	
В	LEG FRONT	2 PCS	2	M8 FLAT WASHER 💿	8 PCS	
С	LEG BACK	2 PCS	3	M8 SPRING WASHER	8 PCS	
			4	M5 ALLEN KEY (BALL SHAPE)	1 PC	





MODEL : BBT 8054 - BENCH


ASSEMBLY INSTRUCTIONS


Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS : 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed. 2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread. 3. Keep all hardware parts out of reach of children.

NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

PART LIST			HARDWARE LIST			
ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY	
A	BENCH	1 PC	1	JCBB Bolt M8 x 45mm	8 PCS	
В	LEG	4 PCS	2	M8 FLAT WASHER 💿	8 PCS	
		. <u> </u>	3	M8 SPRING WASHER	8 PCS	
			4	M5 ALLEN KEY (BALL SHAPE)	1 PC	
			L	1		





2 OF 2

MODEL : BBT 4074 - DT

ASSEMBLY INSTRUCTIONS

1 OF 2

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS : 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed. 2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread. 3. Keep all hardware parts out of reach of children.

NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed : Screwdriver (not provider).

	PART LIST			PART LIST			
	ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION		QTY
	А	TABLE TOP	1 PC	1	JCBC BOLT M6 x 35mm	••••••••••••••••••••••••••••••••••••••	8 PCS
	В	LEGS	4 PCS	2	M6 SPRING WASHER	0	8 PCS
-				3	WOOD SCREW M4 x 32mm		8 PCS
				4	M4 ALLEN KEY	~	1 PC

