




Round Dining Table CF2012




PART LIST




HARDWARE LIST







Step 1 . Attach top rails (parts C) to pedestal (part B) using small flat washers (part #6), small spring washers (part #5), bolts (part #1) and allen wrench (part #8).



Step 2. Attach legs (part D) to pedestal (part B) using flat washers (part #4), spring washers (part #3), hex nuts (part #2) and wrench (part #7).



Step 3. Lay table top (part A) upside down on a soft flat surface, such as carpet. Attach top rails (part C) to table top (part A) using small flat washers (part #6), small spring washers (part #5), bolts (part #1) and allen wrench (part #8).



Step 4. Carefully turn assembled unit upright.

