



## Outdoor Wicker Loveseat CO6222



## PART LIST




## HARDWARE LIST

#1	#2	#3	#4
M6*25mm	M6*40mm	M6mm	M6mm
Short Bolt 2 PCS (Extra 1)	Long Bolt 9 PCS (Extra 1)	Flat Washer 11 PCS (Extra 1)	Allen Wrench 1 PC

Step 1. Lay left arm panel (part B) down on a soft flat surface, such as carpet, as shown below.


Attach seat panel (part D) to left arm panel (part B) using short bolt (part #1), long bolts (part #2), flat washers (part #3) and allen wrench (part #4).

NOTE: Please do not fully tighten bolts until unit is fully assembled.



Step 2. Attach back panel (part C) to left arm panel (part B) and seat panel (part D) using long bolts (part #2), flat washers (part #3) and allen wrench (part #4).


NOTE: Please do not fully tighten bolts until unit is fully assembled.



Step 3. Attach right arm panel (part A) to seat panel (part D) and back panel (part C) using short bolt (part #1), long bolts (part #2), flat washers (part #3) and allen wrench (part #4).


NOTE: Please fully tighten all bolts at this time.

It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed



Step 4. Insert seat cushion cores (part F) into seat cushion covers (part E).

Insert back cushion cores (part H) into back cushion covers (part G).



Step 5. Carefully turn unit upright. Place seat cushions and back cushions as shown below.

