


7 Piece Wicker Sofa Set CO7181




PART LIST

Α	В	D	E	F
(coffee table)	(coffee table)	(armless chair)	(armless chair)	(armless\corner chair and coffee table)
Wicker Top 1 PC	Side Panel 2 PCS	Seat Panel 4 PCS	Back Panel 4 PCS	Side Panel 12 PCS
G	K	M	N	С
(coffee table)	(corner chair)	(corner chair)	(corner chair)	(armless & corner chair)
Glass Top 1 PC	Seat Panel 2 PC	Back Panel 2 PCS	Arm Panel 2 PCS	Seat Cushion 6 PCS
1	O	Р		1
(armless & corner chair)	(corner chair)			
Long Back Cushion 6 PCS	Short Back Cushion 2 PCS	Pillow 2 PCS		

HARDWARE LIST


L ₁	L ₂	Н	J
			2
M6*38mm	M6*55mm	M6mm	M6mm
Short Bolt with Washer 32 PCS	Long Bolt with Washer and Nut 44 PCS	Allen Wrench 2 PCS	Wrench 2 PCS

EXTRA HARDWARE LIST



Step 1. Lay wicker top (part A) upside down on a soft flat surface, such as carpet, as shown below. Attach side panels (part B) to wicker top (part A) using short bolts with washers (part L1) and allen wrench (part H).

NOTE: Please do not fully tighten bolts until unit is fully assembled.




LI ((L) X²

H **→** x1

Step 2. Attach side panels (part F) to side panels (part B) using short bolts with washers (part L1) and allen wrench (part H).


NOTE: Please fully tighten all bolts at this time.



L1 (C) x8

H • x


Step 3. Carefully turn the unit upright. Place glass top (part G) on wicker top (part A).



Step 4. Lay back panel (part E) upside down on a soft flat surface, such as carpet, as shown below.


Attach seat panel (part D) to back panel (part E) using long bolts with washers and nuts (part L2), allen wrench (part H) and wrench (part J).

NOTE: Please do not fully tighten bolts until unit is fully assembled.




Step 5. Attach side panels (part F) to back panel (part E) and seat panel (part D) using short bolts with washers (part L1), long bolts with washers and nuts (part L2), allen wrench (part H) and wrench (part J).

NOTE: Please fully tighten all bolts at this time.




Step 6. Carefully turn the assembled unit upright. Add seat cushion (part C) and long back cushion (part I) as shown below. Repeat steps 4-6 to assemble remaining armless chairs.




Step 7. Lay back panel (part M) upside down on a soft flat surface, such as carpet, as shown below. Attach arm panel (part N) to back panel (part M) using long bolts with washers and nuts (part L2), allen wrench (part H) and wrench (part J).

NOTE: Please do not fully tighten bolts until unit is fully assembled.




Step 8. Attach seat panel (part K) to back panel (part M) and arm panel (part N) using long bolts with washers and nuts (part L2), allen wrench (part H) and wrench (part J).

NOTE: Please do not fully tighten bolts until unit is fully assembled.




Step 9. Attach side panel (part F) to arm panel (part N) and seat panel (part K) using short bolts with washers (part L1), long bolts with washers and nuts (part L2), allen wrench (part H) and wrench (part J).

NOTE: Please fully tighten all bolts at this time.



Step 10. Carefully turn the assembled unit upright. Add seat cushion (part C), long back cushion (part I) and short back cushion (part O) as shown below. Repeat steps 7-10 to assemble remaining corner chair.



Step 11. Add pillows (part P) as shown below.

