

Installation manual for:

2067G30

Dimensions:D30" H24" L13(Height Is Adjustable)

Collection: Weston

Bulb Type:MR11GU10-3K bulb included

Lamp Frame Weight (1bs):37.1

Total Weight (1bs):106



Thank you for choosing our product(s).

Our Company is actively involved in every step of the production.

Our product(s) are designed to be utilized for every application that graces your home or business.

We pride ourselves in providing the most prompt and courtesy service to all of the valued customers.

Please find the enclosed detailed instruction and read carefully for proper installation.

If you have any questions, please contact the retailer where the purchased was made.



SAFETY

Warning: MAKE SURE THE ELECTRICITY TO THE WIRES YOU ARE WORKING ON IS SHUT OFF. BY EITHER REMOVING THE FUSE OR TURNING OFF THE CIRCUIT BREAKER.


CAUTION

- Before assembling the lighting fixture, please read all instructions carefully.
- All frame & crystal components are fragile, please handle with care.
- Required supply circuit : 110 130V/60Hz
- Labeled wires are "L" for live wire, "N" for neutral wire, "E" for ground wire.
- Never install fixture on damp ceiling, the room should be dry and well ventilated
- All electrical components must be installed by a licensed electrician and in accordance with the National Electrical Code and the appropriate local electrical codes.

Unpack the Package

Please open the box carefully and check all the items are inside the box. If you have any installation, assembling and missing parts questions, where you purchase from and any other relevant information ready, our customer service team will provide comprehensive and worry free service to our valued customers.

Frame Parts List



2067G30 D30" H24" L13(Height Is Adjustable)

Step 1

Please use the parts list to ensure you are not missing any parts

2067G30

PARTS LIST

Thirto Eloi								
part	picture	Description	Parts Number	Qty	Check list			
ZA	‡1 1 ‡	Crossbar		1				
ZB		30"Metal canopy		1				
ZC		Knurled nut		6				
P1		Power Cord 18# 144″		13				
P2		0.7"Metal		13				
Р3		M4 Flat Metal screw		26				
P4	•	1.8"Metal plate		13				
P5		5"Metal Tube		13				
Р6	=0	GU10 Socket Suitable for GU10 W1.38"		13				
P7	am()	M4 Round Metal screw		26				
A		20"Crystal Rod		13				


2067G30 D30" H24" L13(Height Is Adjustable)

part	picture	Description	Parts Number	Qty	Check list

03)

(04)

Step 2 Canopy installation instructions



"L" = Hot wire

"N" = Neutral wire


"E" = Ground wire

IMPORTANT: Test sockets with bulb before dressing the fixture.

- 1 .Drill a $\phi 0.7''$ hole in the ceiling reinforcment to allow a $^{11}\!\!/_{16}''$ threaded rod to pass through.
- 2 .Attach the electrical box to the ceiling reinforcment and pass the $^{11}\!\!/_{\!16}$ threaded rod through the box and secure it to the heavy duty hickey.
- 3 . Pass the fixture wires and ground wire through the loop, canopy ring, center hole of canopy and the heavy duty hickey.
- 4. Pull ceiling wires down through the fixture box and make connection.
- 5 .Secure mounting bracket to the junction box.
- 6 . Fix the fixture to the mounting bracket with knurled nuts.

2067G30 D30" H24" L13(Height Is Adjustable)

Frame Assembly Diagram



2067G30 D30" H24" L13(Height Is Adjustable) Step 3

Frame Assembly Instructions


Installation:


Please read all instructions carefully. Before you proceed to install, make sure. that the power supply is turned off and remains off until installation is complete. Please note that each part has been assigned a number. Please proceed in a numerical order.


When replacing the Bulb, just unscrew the top and side!
There is a wire clip in each socket inside the metal canopy.
If you want to adjust the hanging length of the socket,
you need to loosen the wire clip to adjust it.
After adjusting, you can install the Chandelier.
1. Fix the crossbar (01) to the installation 4" junction-box(J-box).
2. Fix the Fixture(02) to the Crossbar(01) with knurled nuts(03).

3. As the crystal dressing instruction, hang the crystal parts.










Step 4 Crystal Dressing Instructions

1. Hang crystal "A" to the lamp body and fixed with M4 screw.

2067G30 D30" H24" L13(Height Is Adjustable)

Crystal Dressing Diagram

When dressing the chandelier with the crystals please remember to wear either rubber or cotton gloves. So as to prevent any damage or smudging on the crystals.



Congratulations!

You are now done installing your Elegant Lighting fixture. Sit back and admire each crystal as it will become the statement piece for your room/house.

Thank you.

Cleaning and Maintenance of Chandelier Frame
The finish on our chandelier frames and fixture
frames is protected by a durable coating of
lacquer. To clean, use a clean soft, dry cloth. Do
not use any metal polishes, cleaners, abrasives
or any substance which could remove the
protective finish. Failure to follow these
instructions automatically voids the guarantee.

Cleaning and Maintenance of Crystals Wet a soft cotton fabric in clean warm water and wipe gently, then polish with a dry soft cotton fabric.

To Order Crystal Replacement Parts
Should you require replacement crystals or pins
(the metal connectors attaching the crystals),
contact the store where the product was
purchased. For ease of ordering, you may use the
original crystal trimming instructions provided
with this product and circle the items you wish
to order, indicating the quantity by writing the
number needed adjacent to the circle. You will
be contacted with prices prior to shipment. All
orders must be pre-paid.

Elegant Lighting Warranty

The finish and frame of your new chandelier or fixture are warranted for a period of one (1) year from the date of purchase. Our company will, at its option, repair or replace any frame that has a defect in the materials or workmanship during the warranty period. All crystals are guaranteed for their original quality during the life of the chandelier. Breakage is not covered by this warranty.

To make a claim under this warranty, contact our customer service department. A written return authorization form will be sent to you with specific instructions.

Returns and Conditions of Warranty

Returns must be pre-authorized by contacting the retailer where you made your purchase.. Returns will only be accepted with a written return merchandise authorization and return shipping charges pre-paid. We reseserve the right to inspect all returned merchandise to fully determine the nature of any defect. This guarantee shall not apply to any product that has been changed, altered or otherwise modified, nor shall it apply to any product that has been repaired or altered by anyone other than a pre-authorized facility. We will not be responsible for any breakage or damages incurred during transit, nor for crystal parts or metal frame part that have been subject to misuse, negligence, accident or inappropriate handling. Also, we will not be held responsible for damage incurred during improper installation or wiring by others, nor for damages resulting from a failure to follow the recommended maintenance or installation procedures. This guarantee is issued in lieu of any and all other guaranteed or warrantee, whether written or implied and any and all other obligations or liabilities. Further, we neither authorize nor permit any other person or firm to assume for us, any liability in connection with the sale of our products.