

Collection: Fae

Installation manual for:

LDOD3003-6PK D3.5"H16.9"L3.5"

## **INSTALLATION INSTRUCTIONS:**

- 1. Slide the switch to the "ON" position.
- 2. Insert the housing (P4) into the top cover (P1) and twist to lock.
- 3. Firmly slide the post (P5) into the housing (P4).
- 4. Attach the post (P5) to the stake (P6).
- 5. Insert the stake (P6) firmly into the ground.
- 6. DO NOT use a hammer. For ground with hard soil, to prevent breaking the stake (P6), use trowel to loosen the soil first.

## **CHARGING THE BATTERY:**

For optimum performance, it is best to install the solar light in full sunlight and charge for 10-12 hours before first use. Allow the light to run at least 8-12 entire charging and discharging cycles to reach battery's maximum capacity.

## **REPLACING BATTERY:**

For best performance, replace with rechargeable 1.2V AA battery when performance diminishes.

- 1. Twist and remove the housing (P4) from the top cover (P1).
- 2. Remove the battery cover (P3).
- 3. Replace the old battery (P2) with a fresh 1.2V AA rechargeable battery.
- 4. Put back the battery cover (P3) and the housing (P4).

The end!



## **PART LIST**

Part	Description	Qty
P1	Top Cover	6
P2	Battery Cover	6
P3	Housing	6
P4	Post	6
P5	Stake	6