

VIVA

- Please check your product packaging to make Sure the included accessories are in the "list of standard accessories".if any parts are missing, please contact your local dealer immediately

- Do not allow any sharp objects to come in contact with the cabinet,as it will scratch the surface



- Continuous and prolonged exposure to direct sunlight may cause discoloration to the wood.

- Continuous and prolonged exposure to direct sunlight may cause discoloration to the wood.


- Please avoid using cleaning products that contain bleach or ammonia.

- Wood surface should only be cleaned with wood care products such as soapy water or furniture polish.


MODLE NO : EVAC090CH



ERECTING TOOL



DRAWER'S ADJUST



INSTALLATION INSTRUCTIONS

