




- Please check your product packaging to make ensure the included accessories are on the "List of Standard Accessories". If any parts are missing, please contact your local dealer immediately.
- Do not allow any sharp objects to come in contact with the cabinet, as it will scratch the surface.
  Continuous and prolonged exposure to direct sunlight may cause discoloration to the wood.
- Please avoid using cleaning products that contain bleach or ammonia. Wood surface should only be cleaned with wood care products such as soapy water or furniture polish.

## **MODLE NO: EVCB-GL17**










## DRAWER'S ADJUST



## **INSTALLATION INSTRUCTIONS**

