
INSTALLATION INSTRUCTIONS

FFT1041BN Single hole faucet



Important


We recommend that this product is installed by a qualified professional contractor.


- Please check this product immediately to ensure that it has not been damaged and is complete.
- Please flush the water system to ensure that no debris or any other impurities can enter the taps.
- Turn off water supply before commencing work.
- Please read these instructions carefully and keep for future reference.


<u>Cleaning</u>

and tighten.


<u>Before use:</u> Unscrew the Aerator and allow the water to run freely for 5 minutes. Then screw the filter back in place. <u>Periodically:</u> Unscrew the Aerator and remove. Rinse it with running water until any loose debris is cleared. Then replace the Aerator







1



- 4: Tighten the rubber washer, the plastic washer with the female screw from the underside of the counter.
- 5: Check that the faucet is correctly positioned, fully tighten the female screw.
- 6: Connect the water supply pipes to the tail of supply lines with the hot water and cold water.

This faucet meets or exceeds the following standards: ASME A112.18.1/CSA B125.1/NSF61-9

 (\mathfrak{O})

This product has been tested and certified by IAPMO.

IAPMO LISTED