

E-Commerce by Enitial Lab

ASSEMBLY INSTRUCTIONS

MODEL # FGI-2070C21

Questions?

GIVE US A CALL: 1-888-980-5122 MON – FRI 8:30AM – 5:30PM (PST)

TOOLS REQUIRED



(Not Included)



Philips Screwdriver (Not Included)




2 - People Recommended





The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.








Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



CHECK BEFORE STARTING

Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

Are there any irregularities or flaws in the parts? We can send replacements!

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.
















Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.


Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CAM LOCK FASTENER ASSEMBLY **INSTRUCTIONS**


Note :

Every cam lock bolt must have a cam lock connector in order to fasten the parts together.










Screw the cam bolt into panel.




Align the cam lock with its side opening (or arrow) pointing to cam bolt.


cam bolt

cam lock






Insert the cam bolt into the bolt hole of joint panel.




Turn the cam lock clockwise gently until it will not turn any more.

BUFFET FGI-2070C21

- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS





HARDWARE							
1) 20PCS	(2)20PCS 0.47"	(3)46PCS 0.98"	(4)11PCS				
		0.98					
(5) 8PCS	(6)20PCS	(7)1PC	82PCS				
Oum	Oppp		(The second seco				
(9) 2PCS	10 2PCS	1 4PCS	12 1PC				
9	Fixed						


ACCESSORIES									
A1)4PCS	A2)4PCS	(A3)1PC	(A4)1PC	A5)16SETS					
A6 4PCS	A72PCS	A8)2PCS	A91PC	(A10)1PC					
(A11)1PC	(A12)1PC	A13 2PCS	(A14)1PC	(A15)1PC					
D	(I) IIII								


GET READY Please group boards as below.								
	▲1PC	©2PCS	• • • • • • • • • • • • • • • • • • •	•1PC				
●1PC ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	• • • • • • • • • • • • • • • • • • •	●1PC : : : :	()1PC					
●1PC : : : : : : : :	①2PCS ②2P	CS D1PC	· · · · · · · · · · · · · · · · · · ·	 Body				
		e		Doors /Shelf				

























18

Accessory A9 x 1PC Accessory A10 x 1PC Accessory A11 x 1PC Accessory A12 x 1PC Accessory A13 x 2PCS Accessory A14 x 1PC





Front 4

19

(√)

ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

