





HARDWARE




WEATHERLY COLLECTION GARDEN BENCH ASSEMBLY INSTRUCTIONS

Do not fully tighten the bolts until all bolts are started. Once all bolts are inserted, then go back and tighten all the bolts.



- 1) Attach Bench Back to Bench Base using one A bolt in the upper hole on each side
- 2) Attach center supports with four A bolts



- 3) Attach the Leg Assembly to the Bench Base using two A bolts in the front, one A bolt in the arm, and one B bolt in the leg
- 4) Repeat on other side

BENW3/BENW4
03.20.15

highwood[®]
NATURE'S CLOSEST RIVAL

For information on Care and Cleaning your **highwood**[®] product visit www.highwood-usa.com/care.html
Visit our Website and Facebook page to see more **highwood**[®] products!
www.highwood-usa.com www.facebook.com/highwoodUSA