




Weatherly Collection Dining Chair with Arms


Assembly Guide



HARDWARE

A  x4
1/4"-20 X 1.5"

B  x4
1/4"-20 X 2"

C  x2
1/4"-20 X 3"

IMPORTANT!

DO NOT fully tighten the bolts until all bolts are started. Once all bolts are inserted, go back & tighten all the bolts.

Retain these instructions for future reference

INCLUDED TOOLS

