

HARDWARE

x10

1/4"-20 X 1-3/4"

IMPORTANT!

DO NOT fully tighten the bolts until all bolts are started. Once all bolts are inserted, go back & tighten all the bolts.

Retain these instructions for future reference

INCLUDED TOOLS



3) With the chair still on its side, attach the Back to the Arm

using one A bolt.

4) Attach the Seat to the Leg using two A bolts.

5) Flip chair onto its other side and repeat Steps 3 & 4.

BACK



ELK OUTDOORS

by highwood®

For information on Care and Cleaning or to register your ELK OUTDOORS product by *highwood*®, please visit www.highwood-usa.com.

SEAT

EO-CLAS1 08.22.2018 PAGE 1 OF 1