






Exhilarating by Design

Volkano Erupt Glass Soap Dish

Installation Guide

Code: V1523, V1524, V1525



Parts Included	QTY
A - Glass Soap Dish	1
B - Screw	2
C - Set Screw	1
D - Allen Key	1
E - Bracket	1

Model #	Description	Finish	Weight (lb)	WxHxD (mm)	WxHxD (Inches)	Metal Type
V1523	Erupt Glass Soap Dish	Chrome	1.6	100 x 58 x 100	4 x 2.3 x 4	Brass
V1524	Erupt Glass Soap Dish	Brushed Nickel	1.6	100 x 58 x 100	4 x 2.3 x 4	Brass
V1525	Erupt Glass Soap Dish	Matte Black	1.6	100 x 58 x 100	4 x 2.3 x 4	Brass

Warranty: 2 Years

Care & Maintenance: A periodic wash using warm water and a soft cloth will retain the high quality finish of your Volkano product for many years to come. ON NO ACCOUNT should any household bleaches, detergents, abrasive polishes, steel wool or other cleaning agents be used on this item.

