


## Quick Access Smart Dial

### Button Operation:

**On/Off:**  
Press and hold

**Change Auto Program:**  
Short press; new program will be announced and start

**Smart Dial Operation:**  
Turn left or right to recline or incline



## Sounds

Select **Sounds** from the home screen menu display. Use the directional buttons to navigate between the following settings:

**Sound:** Select from Nature sounds

**Volume:** Set volume level

**BEEP:** Set to **OFF** to stop sounds from remote

To play Nature Sounds, Bluetooth must remain set to **ON** prior to selection the sound choice.

## Chromotherapy Programs

Select **Lights** from the home screen menu display. Navigate to **Themes**, then use the directional buttons to choose between the following themes. Press **OK** to select.

**Solid** – Single color light

**Breathe** – Single color that dims, then brightens in repetition

**Wake up:** Blue enriched lights to boost energy level - gradual brightness

**Wind down** – Colors of sunset absent blue waves – gradual darkening

**Multi-wave** – All the colors of the rainbow morphing into each other

**Multi-rotate** – Colors rotate from one to another

## Intelligent Voice Control

To Active Voice Mode say:

**“Switch to Voice Mode”**

**Note:** Once you've activated voice control, give a command within 5 seconds, or you will have to re-activate the voice function.

Once activated, use the voice commands below:

<b>Power On</b>	<b>Healthy Breath</b>
<b>Switch Off</b>	<b>Massage Extend</b>
<b>Activate Massage</b>	<b>Relaxation</b>
<b>Sports Refresh</b>	<b>Air Bag Massage</b>
<b>Extension</b>	<b>Demo</b>
<b>Rest &amp; Sleep</b>	<b>Zero Gravity</b>
<b>Neck &amp; Shoulder</b>	<b>Start Heat</b>
<b>Waist &amp; Spine</b>	<b>Heat Off</b>
<b>Deep Shiatsu</b>	

## Share a photo and tag us:

@Infinitymassagechairs

@infinity\_chairs

@Infinitymassagechairs

Don't forget to use #Infinitymassagechairs

# INFINITY®

72 Stard Road, Seabrook, NH 03874  
603-910-5000  
www.infinitymassagechairs.com  
Version 1.3

# INFINITY®

## Quick Start Guide

### Dynasty 4D Massage Chair

# INFINITY®

### Multi-Functional Screen —

Use the directional buttons below to navigate these menu screens. Then press ok to select

**Power** — Powers up the remote or returns the chair to the exit position and powers down remote

**Home** — Shortcut to the home page of all menu screens


**OK** — After navigating to the command desired on the display, push OK to select.

**Zero Gravity** — Press for Zero Gravity 1, press again for Zero Gravity 2, press again to restore to recline

**Foot Roller** — Press to turn off Foot Roller, press again to resume Foot Roller

**Footrest** — Press and hold up arrow to bring foot rest up, Press and hold down arrow to bring footrest down

**Leg Length** — Press and hold right arrow to extend the leg length adjustment, press and hold the left arrow to retract the leg length adjustment



### In-Use Screen:

After a massage program is selected, displays all settings to that program



**Pause** — Press pause to immediately stop all massage chair activity, press again to resume



**Auto** — Shortcut to the Auto Programs menu screen



**Directional Button** — Press up, down, left or right to navigate the display screen



**Back Adjustment** — Back mechanism position adjustment; press and hold up to raise, press and hold down to lower. Use during initial body scan fine tuning or in manual partial or point zone mode



**4D** — Press to increase or decrease 4D intensity of back mechanism. In-use screen displays intensity dial



**Seat Back Position** — Press and hold down arrow to recline the seat back, press and hold the up arrow to upright the seat back