

MOEN®

Illustrated Parts


■ Order by Part Number

*There is more than one version of this model.
Page down to identify the version you have.*

M-POWER® Modern Style Electronic Soap Dispenser	
MODEL	FINISH
8560	Chrome
8560BL	Matte Black
8560BN	Brushed Nickel

Spacer, Gasket, and Mounting Stud
(For use with top mounted sink lip heights
up to approximately 13/16 in.)

- 181149** Chrome
- 181149BL** Matte Black
- 181149BN** Brushed Nickel



Soap Vandal Sheathing
(Soap Tube not included)

182419

Soap Net
182418

Wire Vandal Sheathing
182420

Mounting Hardware

146190

Installation Tool

118305

D-Cell Battery Box
(Batteries not included)

182421

Soap Tube, O-ring,
Spout Barb, & Soap Net
(Tube Sheathing not included)
(Nylon Washer is for use on
models made before Jan. 1, 2017)

182417

Mounting Bracket,
Vandal Shield &
Mounting Hardware
(Key included)

182416

Soap Dispenser –
Sensor, Bracket, & Screw
(Only for use with
Soap Dispenser)

182422

Electronics Box

182415

Non-drip Foam Soap Pump

182413

1500mL Soap Bottle

182414

AC Conversion Kit


- AC Transformer
(up to 8 devices)
104630
- Faucet AC Connector
(1 per device)
182538

■ Order by Part Number

M•POWER®	
Modern Style	
Electronic Soap Dispenser	
MODEL	FINISH
8560	Chrome

Spacer, Gasket, and
Mounting Stud
*(For use with top mounted
sink lip heights up to
approximately 13/16 in.)*

181149



Soap Tube, O-ring,
Spout Barb, & Soap Net
(Tube Sheathing not included)

182417

Mounting Bracket,
Vandal Shield &
Mounting Hardware
(Key included)

182416

Soap Vandal Sheathing
(Soap Tube not included)


182419

Soap Net

182418

Wire Vandal Sheathing

182420



Mounting Hardware

146190

Soap Dispenser –
Sensor, Bracket, & Screw
*(Only for use with
Soap Dispenser)*

182422

Installation Tool

118305

Electronics Box

182415

D-Cell Battery Box
(Batteries not included)

182421

Non-drip Foam Soap Pump

182413

1500mL Soap Bottle

182414

