

CODE NUMBER

3919093

DESCRIPTION

1.0 gpf, Rough Brass Finish, Top Spud, Single Flush, Hardwired, Solenoid-Operated, 24V, Royal® Concealed Solenoid (less sensor) Urinal Flushometer.

DETAILS

Flush Volume: 1.0 gpf (3.8 Lpf)
Finish: Rough Brass (RB)
Power Type: Hardwired (HW)

· Valve: Diaphragm

• Valve Body Material: Semi-red Brass

• Fixture Type: Urinal

• Fixture Connection: Top Spud

• Rough-In Dimension: 13 ½" (343mm)

Spud Coupling: ¾" (19mm)
Supply Pipe: ¾" (19mm)
Voltage: 24V (24V)

FEATURES

• 24 VAC 50/60 Hz non-hold-open integral solenoid operator

• Vacuum Breaker

 PERMEX® Synthetic Rubber Diaphragm with Dual Filtered Fixed Bypass

• No External Volume Adjustment to Ensure Water Conservation

- Concealed electronic operated, diaphragm type, rough brass closet flushometer
- User friendly three (3) second Flush Delay and Non-Hold-Open Integral Solenoid Operator
- 1" I.P.S. Wheel Handle Bak-Chek® Angle Stop
- Diaphragm, Stop Seat and Vacuum Breaker to be molded from PERMEX® rubber compound for Chloramine resistance
- Elbow Flush Connection and Coupling for 11/2" NPT Back Inlet (for connection in the pipe chase — flush connection through the wall not provided by Sloan)
- Model ES flushometers are activated remotely by an electric push button (not included). "ES" flushometers offer solutions for installations that require automatic, remote or other control requirements



COMPLIANCES & CERTIFICATIONS







(cUPC Certified, BAA Compliant, UL Certified)

RECOMMENDED SPECIFICATION

Valve Body, Cover, Tailpiece and Control Stop shall be in conformance with ASTM Alloy Classification for Semi-Red Brass. Valve shall be in compliance with the applicable sections of ASSE 1037 and ANSI/ASME 112.19.2.

ELECTRICAL SPECIFICATIONS

Solenoid Operator: 24 VAC

VALVE OPERATING PRESSURE (FLOWING)

15–80 PSI (103–552 kPa). Specific fixtures may require greater minimum flowing pressure - consult manufacturer requirements.

DOWNLOADS

- Concealed Flushometer Installation Instructions for Stainless Steel Fixtures
- Control Stop Repair and Maintenance Guide
- Flush Connections Flanges Repair and Maintenance Guide
- Tail Piece Repair and Maintenance Guide
- Royal Manual Diaphragm Flushometer Repair and Maintenance Guide
- Additional Downloads

NOTES

All information contained within this document subject to change without notice.

Looking for other variations of the ROYAL 613 ES product? View the general spec sheet with all options.

Find a compatible urinal for this flushometer.
Find a compatible water closet for this flushometer.

Phone: 800.982.5839 • Fax: 800.447.8329 • sloan.com



ROUGH-IN

