



Step 4 Parts list 115112-BAF-PC/ BG/ MB



NO.	Description
1	Body
2	Base
3	Hot and cold indicator
4	Filter
5	Ceramic cartridge
6	Nut
7	Cover
8	Screw
9	Pipe
10	Lock nut
11	Rubber washer
12	Metal washer
13	Gasket
14	O-ring
15	Hot & cold hose
16	Black cap
17	O-ring
18	Handle




Single Handle Basin Faucet

product is CUPC, NSF/ ANSI 61, LEAD FREE and ADA certified.


ASME A112.18.1/CSA B125.1




The tools might be applied to the following places:



Step 1 Faucet installation



- 1. Unscrew the pre-assembled washers & lock nut and screw.
- 2. Screw rubber washer, metal washer onto the pipe under sink and screw with lock nut and screw.




- 3.Connect the flexible hoses to water supply valve (not included) and copper tubes, and tighten it with adjustable wrench. DON'T OVER TIGHTEN!
- Caution: make sure connect the hot and cold flexible hose to supply valves correctly.



Warning: The supply valves are not included, please purchase them in plumbshop.

Step 2 Checking and testing



- 1.Turn the faucet handle all the way on, turn on hot and cold water supply and flush water lines for one minute.
- 2. Check all connections at arrows for leaks, re-tighten it if necessary.



BUT DON'T OVERTIGHTEN

Step 3 Cleaning and care

Daily cleaning and care are required in order to keep the product shining and properly working.

- 1 Clean it with water and dry it with soft cloth.
- 2 Clean the product with gentle liquid or glass cleaner.
- 3 Don't use acid cleaner.
- 4 Don't clean with abrasive material, abrasive paper or knife.