MODEL: F6-0009



TUB FAUCET INSTALLATION GUIDE

BEFORE YOU BEGIN

- 1) Shut off water supply.
- 2) Carefully inspect waste and supply tubing for signs of damage.
- 3) Replace waste or supply tubing if necessary

INSTRUCTIONS

- 1) Apply tape or putty to both ends of hot and cold supply nipples (8). Thread the nipples into risers (7).
- 2) Attach the rubber washer into riser nut, connect it with faucet body (5).
- 3) Set the faucet onto tub and nipples go through the tub wall holes.
- 4) Slid the metal washer (9) and install the lock nut (10) then tighten with wrench.
- 5) Set the handles (6) on faucet body with screws.
- 6) Attach the rubber washer into cradle nut (4), connect it with faucet body.
- 7) Assemble the hand shower (1) (2) and hose (3) with rubber washer, then to connect with cradle.
- 8) Connect the water supply lines to riser nipples.
- 9) Turn on main water supply and check all connections for leaking.

COMPLETE INSTALLATION

Note: All nuts connections, hand tighten first then quarter turn tighten by wrench. Don't over tighten the nut.

