FINE FIXTURES

APRON BATHTUB
# INSTALLATION INSTRUCTIONS

Important Information

The bath must only be supported by the feet or base. Do not support the bath by the rim.

Before installing a rim-mount bath faucet, refer to the online product specification sheet. Ensure clearance under the rim before drilling faucet holes in the rim.

Provide adequate floor support. Refer to the specification sheet for specific floor-loading requirements.

Make sure the subfloor is level. Provide drain access from below. Provide access to all plumbing connections. Observe all local building and plumbing codes.

Conventional woodworking tools and materials for better installation

100% Silicone Sealant

*Drop cloth
*Construction Adhesive

1. Construct a plumb stud pocket. Refer to the specification sheet.

**2.** Install the rough plumbing.

3. Install the drain to the bath.

4. For mortar bed installation, set the basin area in 1" (25 mm) to 2" (51 mm) of mortar cement.

5. For adhesive installation, apply a generous amount of construction adhesive to the bath feet or base.

6. With help, lift the bath into position. Verify level. Ensure the feet or base are fully supported.

7. Connect the bath drain to the drain pipe. Position a protective liner in the bath basin.

8. Drill small pilot holes through the flange at the studs.

9. If there are gaps, fill them with a shim.

Side View

Stud

Shim

Flange

10. Secure the flange to the stud with galvanized nails or screws.

11. Secure 1/4" (6 mm) furring strips to the studs to be flush with the bath flange.

12. Install water-resistant wallboard over the framing. Apply 100% silicone sealant along the seam.

Water-Resistant Wallboard

13. Install the finished wall and deck to within 1/16" (2 mm) of the bath rim.

Finished Material

14. Apply 100% silicone sealant around the bath along the finished walls and deck.

Silicone Sealant