





PHYLRICH®


Defining Luxury Since 1959


INSTALLATION INSTRUCTIONS FOR 1/2" & 3/4" IN LINE VOLUME CONTROL VALVE Valve Numbered: 80607PHY & 80002125 Trim Numbered 2PV


1261 Logan Ave, Costa Mesa, CA 92626 Telephone: 714-361-4830 Fax: 714-617-3120 www.phylrich.com






















Attach handle to handle escutcheon. Tighten spacer nut into the handle so that there is clearance (\sim 1/32") between the handle and the handle base. See clearance diagram shown above.

Step #7.1



Secure handle to the handle escutcheon by tightening the cap screw into the valve stem.



Complete the handle installation by placing the o-ring and decorative cover plate into the recess in the handle.


Phylrich®

Valve shown:

80607PHY 80002125

Rough In Specifications For 1/2" & 3/4" In Line Volume Control

IF YOU DO NOT KNOW THE TRIM NUMBER PLEASE REFERENCE. THIS DRAWING FOR CORRECT VALVE PLACEMENT



ALL PHYLRICH VALVE INSTALLATIONS MUST FOLLOW THE MEASUREMENTS FOR "A" LISTED BELOW. PLEASE CONSULT THE TRIM NUMBER FOR THE CORRECT ROUGH IN DIMENSION.

Phylrich Prod#	Ro	ugh In
2PV101	2	3/8"
2PV104	2	3/4"
2PV105	2	3/4"
2PV109	2	5/8"
2PV111	1	7/8"
2PV112	1	1/2"
2PV120	2	1/8"
2PV121	2	1/4"
2PV123	2	5/8"
2PV137	2	3/8"
2PV137SF	2	3/8"
2PV141	2	3/8"
2PV144	2	1/4"
2PV158B	2	1/4"
2PV158C	2	1/4"

Phylrich Prod#	Ro	ugh In
2PV158D	2	1/4"
2PV158F	2	1/4"
2PV160	2	1/4"
2PV170	2	1/2"
2PV171	2	1/2"
2PV180		3"
2PV181		3"
2PV183		3"
2PV184		3"
2PV190	2	3/8"
2PV234	2	5/8"
2PV240		3"
2PV241		3"
2PV242		3"

Phylrich Prod#	Ro	ugh In
2PV243		
2PV244		3"
2PV270		3"
2PV271		3"
2PV272		3"
2PV273		3"
2PV274		3"
2PV338B	2	1/2"
2PV338C	2	1/2"
2PV338D	2	1/2"
2PV338F	. 2	1/2"
2PV361	2	3/8"

Doralfe Prod#	Ro	ugh In
D2PV100	. 2	1/4"
D2PV102	. 2	1/4"
D2PV103	. 2	1/4"
D2PV130	. 2	1/4"
D2PV134	.2	1/4"
D2PV137	. 2	1/4"
D2PV205	. 2	3/4"
D2PV206	. 2	3/4"