

- 1 3D intensity level
- 2 Active airbags
- 3 Active rollers
- 4 Time left
- 5 Indicators
- 6 Back-roller position & direction

Menu key to select function

7 Bluetooth connected

While in-use screen is showing



Press OK for shortcut to zero gravity
Press Up on directional button to increase back roller speed
press Down on directional button to

decrease back roller speed

Airbag Intensity

When in-use screen is showing:



- Use directional buttons
- Right side to increase intensityLeft side to decrease intensity

When main menu is showing:

Navigate to **AIRBAG** and press **OK** navigate to **FORCE** select **OK**Set intensity desired by selecting 1 (lowest) through 5 (highest) and pressing **OK**





Note: Airbags must be active to set intensity level

Share a photo and tag us:



@Infinitymassagechairs



@infinity_chairs



@Infinitymassagechairs

Don't forget to use #lovemyinfinitychair

INFINITY

72 Stard Road, Seabrook, NH 03874 603-910-5000 www.infinitymassagechairs.com

INFINITY®

Quick Start Guide



Smart Chair X3 Massage Chair

