


ProHeat Series Sauna Heaters Installation and Operation Manual



MODELS

P300/KIP30W1 P450/KIP45W1 P600/KIP60W1 P800/KIP80W1 P600-3/KIP60W3 P800-3/KIP80W3

CONTROLS

HeatPad10 HeatPad15



IMPORTANT! This manual must be left with owner, manager, or operator of sauna after it is used by electrician!

TABLE OF CONTENTS

1.	WARNINGS!	. 3
2.	INSTALLATION OF WALL MODEL HEATER	. 4
	2.1. Sauna Heater Wiring and Hookup 2.2. Sauna Control Panel Wiring and Hookup 2.3. Sauna Rock placement 2.4. Testing Sauna Heater 2.5. Troubleshooting 2.6. Caution! Electrician Or Service Person! 2.7. High Limit Control	. 7 . 8 . 8
3.	ROOM CONSTRUCTION - GENERAL INFORMATION	
4.	MAINTENANCE INSTRUCTIONS	
5.	WARNINGS!	12
6.	GUARANTEE	13

WARNINGS!

Do not smoke, use alcohol, or exercise in the sauna!

Do not exceed 30-minutes in the sauna at one time, as excessive exposure can be harmful to health. The sauna should not be used as an endurance test!

Persons with poor health should consult their physicians before using the sauna!

Avoid fire, do not place any combustible material over the sauna heater (towels, bathing suits, wooden bucket or dipper)!

Use only clean water on the stones - do not use pool or spa water, as chlorine gas can be produced and the heating elements can be damaged!

Keep away from the heater when it is hot. The stones and outer surface of the heater may burn your skin.

Do not pour too much water on the stones. The evaporating water is boiling hot.

Do not let young, handicapped or ill people bathe in the saune on their own.

Consult your dodcutor about health-related limitations of bathing.

Parents should keep their children away from the hot heater.

Consult your child welfare clinic about taking little babies to the sauna.

- Age?
- -Temperature of the sauna?
- -Time spent in the warm sauna?

Be very careful when moving in the sauna, as the platform and floors may be slippery.

Hyperthermia occurs when the internal temperature of the body reaches a level several degrees above the normal body temperatures of 98.6°F (37°C). The symptoms of hyperthermia include an increase in the internal temperature of the body, dizziness, lethargy, drowsiness, and fainting.

The effects of hyperthermia include:

- A) Failure to perceive heat
- B) Failure to recognize the need to exit the room
- C) Unawareness of impending hazard
- D) Fetal damage in pregnant women
- E) Physical inability to exit the room
- F) Unconsciousness

Warning - the use of alcohol, drugs or medication is capable of greatly increasing the risk of fatal hyperthermia!

TYPICAL SAUNA HEATER CONTROL INSTALLATION




Figure 1. HeatPad10 / HeatPad15 Digital Sauna Control

INSTALLATION OF WALL MODEL HEATER

- Remove heater from carton and attach hater to wall with supplied screws. Use 2"x4" backing behind heater. Observe proper clearances as per page 5 and 6 and table 1.
- See applicable wiring diagram on page 14 of the HeatPad Precision Sauna Environment Controller. Heater must be permanently installed (no pigtails or plug allowed) and wiring must be done by a licensed electrician, who must follow wiring diagram provided and adhere to local codes. Use proper A.W.G. rated wire size and use copper wire suitable for 194°F (90°C) within
- sauna walls. Use grounding terminals provided in sauna heater, control system, and contactor to properly ground the equipment as per NEC and local codes.
- 3. Inside the heater box there are two signs. Please place the metal "CAUTION" sign on the interior wall of the sauna room directly above the heater in a visible place. Place the metal "WARNING" sign outside, on the door of the sauna room. "MAINTENANCE INSTRUCTIONS" are at the end of this manual.

THE SAUNA ROOM SHALL BE PROVIDED WITH PROPER VENTILATION. WALL-MOUNTED HEATERS-MINIMUM CLEARANCES, MIN-MAX SPACE, AND ADEQUATE VENTILATION DESCRIBED BELOW.

VENTILATION, MIN SQ. IN. INLET AND OUTLET 3 kW and 4.5 kW 10 sq.in. 6 kW and 8kW 20 sq.in.




Figure 2.




Figure 4.

HEATER MINIMUM CLEARANCES CORNER FENCE INSTALLATION




Figure 3.

HEATER MINIMUM CLEARANCES CENTER WALL FENCE INSTALLATION




Figure 3a.

MODEL	INPUT	UT FLOOR AREA		SAUNA ROOM		MIN. SPACING FROM
	KW	Min. Sq. Ft	Max. Sq. Ft	Min. Cu. Ft	Max. Cu. Ft	ADJACENT SURFACES (INCHES)
P300/KIP30W1	3.0	10	20	84	130	3
P450/KIP45W1	4.5	16	30	100	210	3
P600/KIP60W1	6.0	28	40	170	300	4
P800/KIP80W1	8.0	40	65	250	425	5

Table 1

SAUNA HEATER WIRING AND HOOKUP

Refer to table below for proper wire size and amperage. See page 5 and 6 for required clearances. Any wiring within internal sauna walls must be rated 194°F (90°C) and copper wire must be used. Run wire through seal tight flex conduit from wall to heater and connect to junction box at back of heater with 194°F (90°C) connector. Connect to terminals 1 and 2 and connect ground wire to lug marked ground. (Cover plate under heater must be removed first.)

Note! If connection to heater will be made at a later time, bring flex into sauna room 4 - 6" from floor, and leave 3' of flex for hookup (can be cut to right length later).

SAUNA CONTROL PANEL WIRING AND HOOKUP

Refer to HeatPad installation and operation manual.

Models P300/KIP30W1, P450/KIP45W1, and P600/KIP60W1 require a HeatPad10/CX30-U1-U3 sauna heater control. Follow 240V 1Ph (single circuit) wiring on ProHeat series wiring schematic (page 14 of HeatPad installation and operation manual).

Model P800/KIP80W1 requires a HeatPad15/CX45-U1-U3 sauna heater control. Follow 240V 1Ph (single circuit) wiring on ProHeat series wiring schematic (page 14 of HeatPad installation and operation manual).

Models P600-3/KIP60W3 and P800-3/KIP80W3 require a HeatPad10/CX30-U1-U3 sauna heater control. Follow 208V 3Ph wiring on ProHeat Series wiring schematic (page 14 of HeatPad installation and operation manual).

Note! All ProHeat sauna heater hookups require a 10 AWG jumper wire from A1 to A2 on power unit terminal block. See ProHeat series wiring schematic (page 14 of HeatPad installation and operation manual).

SAUNA HEATER (240 V) WITH CONTROL UNIT							
Model	kW	Amps	Voltage	Phase	Wire Size	Control	
P300/KIP30W1	3.0	12.5	240	1	12	HeatPad10/CX30-U1-U3	
P450/KIP45W1	4.5	18.8	240	1	10	HeatPad10/CX30-U1-U3	
P600/KIP60W1	6.0	25.0	240	1	10	HeatPad10/CX30-U1-U3	
P800/KIP80W1	8.0	33.3	240	1	8	HeatPad15/CX45-U1-U3	

SAUNA HEATE	R (208					
Model	kW	Amps	Voltage	Phase	Wire Size	Control
P600-3/ KIP60W3	6.0	16.7	208	3	12	HeatPad10/CX30-U1-U3
P800-3/ KIP80W3	8.0	22.2	208	3	10	HeatPad10/CX30-U1-U3

SAUNA ROCK PLACEMENT

Before testing heater, fill rock cavity with igneous stones provided with heater and fasten metal rock guard at top of heater.

Use only the stones which are supplied with the sauna heater. Wash stones with water hose and place inside of heater box so that rocks are between and around heating elements. However, do not force rocks between elements. Use smaller stones first, and continue to fill heater with larger stones until they are about 2" below rock guard. You may not need all of the stones.

Note! Do not operate heater without stones!

Stones should be placed loosely within heater so that there is good heat circulation around and through them. Stones should completely cover the heating elements, however! Pouring water over exposed elements could cause heater damage!

TESTING SAUNA HEATER

- After sauna heater has been properly wired, according to appropriate wiring diagram and local codes, turn sauna breaker on in the main breaker panel. (Note! Electrician must label "sauna" breaker.)
- Turn thermostatic (heat) control to "on" position. The indicator light will come on to show that the sauna is heating. Set timer to 10- or 15-minutes.
- 3. Within 5-minutes, you should be able to feel heat from heater elements when holding your hand over heater.
- 4. If sauna does not heat, refer to troubleshooting information.
- It is normal for smoke to appear during the first heating, as protective element coating needs to burn off.
 Turn sauna on for 1-hour before using the first time, to eliminate smoking.

TROUBLESHOOTING

- A. If sauna does not operate after initial installation and wiring:
- 1. Check breaker to be sure that it is on. Also, breaker should be correct size.

- 2. Check circuit breaker in contactor to be sure that it has not been shorted out
- 3. Be sure that thermostat and timer are both in on position.

B. If sauna does not operate after initial installation and wiring:

- 1. Check breaker to make sure it is on.
- 2. Check high limit reset button in heater (reset is under the heater) to see if it has been released.
- 3. Call your electrician or service person for further help.

NOTE! A ground fault interrupter (GFI) should not be installed in and does not belong in a sauna. If used, the breaker will trip, and damage could result.

- C. If sauna heater operates, but sauna room does not come up to sauna temperature (160-185°F, (70-85°C)) normal temperature:
- 1. You must allow at least 30-minutes for sauna heat-up time.
- Is sauna thermometer located 6" from ceiling, and is it above or close to sauna heater? (This is proper location for sauna temperature reading.)
 Thermometer readings vary with room heights and location. Eg. 180 °F (82 °C) above sauna heater = 165 °F (74 °C) on opposite wall = 140°F (60 °C) on upper bench level = 120 °F (49 °C) on lower bench level = 100 °F (38°C) at floor level.
- Check for proper wire size, amp size, and proper wiring (according to diagrams and information) also necessary copper wiring.
- Check for placement of stones to make sure they are loosely spaced around elements, to ensure good air flow. Stones packed too tightly will restrict air flow and reduce heating capacity.
- 5. Check for heat loss around or under door or around ceiling light.
- 6. Is room properly insulated.
- 7. Is ceiling higher than 7'?
- 8. After checking all the above, remove rocks and check heater elements for holes or burned areas. (Only if heater has been in use for some time.)

CAUTION! ELECTRICIAN OR SERVICE PERSON!

- 1. Before servicing heater, control, or contactor, turn power off at breaker!
- Open junction box to make sure wires are tightly secured with no loose connections. Heater wire and all connecting wires should be copper.
- 3. Check for burned spots or short in wiring of timer or thermostat.

Warranty on parts is void if installer/ electrician fails to follow necessary wiring information provided or fails to follow code for proper wire size, amperage, etc.

HIGH LIMIT CONTROL

Note! Only persons authorized to carry out electrical installations can reset the high limit control!

Each heater is equipped with a high limit control which is a safety device. If an abnormal heating condition should occur, the heater will automatically shut off, and it will not come on again until it cools.

To reset the high limit, locate the reset button at the bottom front of heater and push upward until contactor kicks in. Be sure that a GFI has not been installed.

Receptacles OR PLUGS are not allowed in a sauna room.

ROOM CONSTRUCTION - GENERAL INFORMATION

A. FRAMING

2" x 4" any suitable wood material, 16" o.c.

B. CEILING LIGHT

No higher than 7'0".

C. INSULATION

R11 Fiberglass with foil back in walls and ceiling, foil facing into room.

D. DRYWALL

See local codes. Is not required in most residences. See local codes commercial. If drywall is used, apply 1" x 2" nailers so that wall and ceiling boards can be attached to solid wood.

E. PANELING

Use kiln-dried, clear, T&G softwood such as California Redwood, Western Red Cedar, Alaska Yellow Cedar, pine, spruce or other suitable wood material (with moisture content not exceeding 11%).

F. BENCHES

Use matching wood of vertical grain. Fasten from bottom to prevent burning of bathers.

G. HEATER FENCE

Is necessary for safety and should be constructed of 1" x 4" or 2" x 4" softwood to match sauna interior. See figures 2 - 4 clearances from sauna heater. Fence should attach to wall and should not be placed higher than top of heater below rock line.

H. DOOR

Must open out and should not have a lock.

I. FLOORING

Concrete, ceramic tile, or heavyduty vinyl.

J. VENTILATION

Should be provided by lower vent close to heater, 4" from floor, and upper vent on opposite wall (if possible) 6" from ceiling or as low as 24" from floor. Vents should be adjustable and should allow air to change 5 times per hour. Sauna shall be provided with intended ventilations as required per the local code authorities.

K. LIGHT

Should be wall-mounted, vapor proof type, with rough-in box mounted flush with inside paneling. It should mount 6' 6" from the floor, not directly over sauna heater, and not over upper

benches; light bulb should not exceed 75 watts.

L. ACCESSORIES

Bucket, dipper and thermometer are essential. Thermometer should be placed over the sauna heater, 6" from ceiling, for correct temperature reading. Other accessories such as hygrometer, sand timer, brushes, etc. are available.

M. MAINTENANCE INSTRUCTIONS

Are included at the end of this manual.

N. WARNING SIGNS

Are furnished with sauna heater. The metal "CAUTION" sign should be fastened to wall, close to heater, in a visible place. The metal "Warning" sign should be fastened outside, to the sauna room door.

WARNINGS!

- * Do not smoke, use alcohol, or exercise in the sauna!
- * Do not exceed 30-minutes in the sauna at one time, as excessive exposure can be harmful to health. The sauna should not be used as an endurance test!
- * Persons with poor health should consult their physicians before using the sauna!
- * Avoid fire, do not place any combustible material over the sauna heater (towels, bathing suits, wooden bucket or dipper)!
- * Use only clean water on the stones do not use pool or spa water, as chlorine gas can be produced and the heating elements can be damaged!
- * Hyperthermia occurs when the internal temperature of the body reaches a level several degrees above the normal body temperatures of 98.6°F (37°C). The symptoms of hyperthermia include an increase in the internal temperature of the body, dizziness, lethargy, drowsiness, and fainting.
- * The effects of hyperthermia include:
- A) Failure to perceive heat
- B) Failure to recognize the need to exit the room
- C) Unawareness of impending hazard
- D) Fetal damage in pregnant women
- E) Physical inability to exit the room
- F) Unconsciousness
- * Warning the use of alcohol, drugs or medication is capable of greatly increasing the risk of fatal hyperthermia!

MAINTENANCE INSTRUCTIONS

- Use only clean water on sauna stones.
 Do not use spa or pool water as it will destroy your heater.
- Clean water should always be used in sauna buckets and water should be dumped out after every use. Scour buckets and dipper occasionally when film collects from usage. Use plastic bucket liner in bucket to prevent water leakage.
- Scrub benches with a soft brush, using soap and water or a mild disinfectant, when needed - about once a week in commercial saunas, or depending on sauna usage. For sanitation, each bather should sit or lie on a towel (this will prolong bench life).
- Remove possible removable flooring and wash waterproof floor with disinfectant (e.g. Pine-Sol) about once a week or as often as needed. Hose off removable flooring to clean.
- 5. To maintain beautiful appearances of sauna heater, remove water stains by wiping with a damp cloth occasionally.
- Sauna heaters require no special maintenance when properly installed by a qualified electrical contractor. After 5-years of usage, the rocks may need replacing if they have crumbled or powdered.
- 7. We strongly recommend a floor that can be easily cleaned (concrete, ceramic tile, or a poured type of flooring). When this is provided, the sauna can be easily cleaned and kept in a sanitary condition with little effort. A carpet is NOT recommended for a sauna! A carpet becomes a perfect breeding ground for bacteria in the moist conditions of a sauna; and a carpet promotes the spread of foot diseases such as athlete's foot.

- 8. In new construction, a floor drain should also be provided, especially in commercial saunas for sanitary cleaning and maintenance.
- 9. Seal wood around glass in door inside and outside with Thompson's Water Seal to prevent warpage.
- 10. When sauna wood becomes stained from perspiration, the wood may be lightly sanded with fine sandpaper to restore beautiful appearance. We do not recommend stains or sealers as toxic vapors may appear when heated.
- 11. The sauna room will heat faster if the higher vent is kept in a closed position when heating. The lower vent may always be kept in an open position.
- 12. Required warning signs should be posted according to the instructions.

Owner of the sauna heater must make sure that the sauna heater is turned off correctly every time after bathing.

Owner of the sauna must obey these maintenance instructions!

WARNINGS!

Do not smoke, use alcohol, or exercise in the sauna!

Do not exceed 30-minutes in the sauna at one time, as excessive exposure can be harmful to health. The sauna should not be used as an endurance test!

Persons with poor health should consult their physicians before using the sauna!

Avoid fire, do not place any combustible material over the sauna heater (towels, bathing suits, wooden bucket or dipper)!

Use only clean water on the stones - do not use pool or spa water, as chlorine gas can be produced and the heating elements can be damaged!

Keep away from the heater when it is hot. The stones and outer surface of the heater may burn your skin.

Do not pour too much water on the stones. The evaporating water is boiling hot.

Do not let young, handicapped or ill people bathe in the saune on their own.

Consult your dodcutor about health-related limitations of bathing.

Parents should keep their children away from the hot heater.

Consult your child welfare clinic about taking little babies to the sauna.

- Age?
- -Temperature of the sauna?
- -Time spent in the warm sauna?

Be very careful when moving in the sauna, as the platform and floors may be slippery.

Hyperthermia occurs when the internal temperature of the body reaches a level several degrees above the normal body temperatures of 98.6°F (37°C). The symptoms of hyperthermia include an increase in the internal temperature of the body, dizziness, lethargy, drowsiness, and fainting.

The effects of hyperthermia include:

- A) Failure to perceive heat
- B) Failure to recognize the need to exit the room
- C) Unawareness of impending hazard
- D) Fetal damage in pregnant women
- E) Physical inability to exit the room
- F) Unconsciousness

Warning - the use of alcohol, drugs or medication is capable of greatly increasing the risk of fatal hyperthermia!

GUARANTEE

This HOTASS SAUNA heater is guaranteed for one-year from date of purchase, and includes all heater parts such as heating elements, controls, contactors, etc.

This guarantee covers faults in manufacture and material only, and includes the exchange of new parts supplied by the manufacturer or importer, after the faulty part has been returned to same. The replacement of parts under warranty does not extend the warranty period beyond the original one-year.

The guarantee does not cover defects caused by normal wear and tear, defects caused by improper installation, poor maintenance, or failure to follow the manufacturer's instructions for installation, use and care, or alterations made to the sauna product.

This guarantee is void if the heater is used improperly, pool or spa water should not be poured over the sauna stones, as chemicals are harmful to the heater; the sauna room must be heated for at least 30-minutes before water is poured over

the stones; only one or two dippers full of water should be poured over the hot stones at one time. This guarantee will be void if a shower has been installed in the sauna room.

This guarantee does not cover delivery costs of the faulty part or costs of the person carrying out the repair in the field. If the sauna heater is returned to the manufacturer or the importer within five-years after date of purchase, the importer will provide free labor for repair, but will charge for parts if date of purchase is past one-year.

This guarantee will be void if installation and wiring is not carried out by a certified electrician or authorized and qualified service representative, who must sign below.

This guarantee will be void if information below is not filled out and returned within 15-days of purchase, and it applies only to original installation of product and to original purchaser.

SAUNA HEATER	
MODEL NUMBER	
DATE OF PURCHASE	
ORIGINIAL OWNER	
ADDRESS	
PURCHASED FROM	
ELECTRICIAL CONTRACTOR	
MUST SIGN HERE	
DATE OF ELECTRICAL	
WIRING & HOOKUP	



HeatPad Precision Sauna Environment Controllers Installation and Operation Manual



MODELS

HeatPad10/CX30-U1-U3 HeatPad15/CX45-U1-U3



IMPORTANT! This manual must be left with owner, manager, or operator of sauna after it is used by electrician!

NOTE!

These instructions for installation and use are intended for owners of saunas, heaters, and control units, persons in charge of managing saunas, heaters and control units, and for electricians responsible for installing heaters and control units. Once the control unit is installed, these instructions of installation and use are handed over to the owner of the sauna, heater and control unit, or to the person in charge of maintaining them.

HEATPAD CONTROL UNIT

Control unit's purpose of use: The control unit is meant for controlling the functions of an electric sauna heater. It is not to be used for any other purpose.

TABLE OF CONTENTS

1.	WARNINGS!
2.	HEATPAD SAUNA ENVIRONMENT CONTROLLER
	2.1. General 4 2.2. Technical Data 4 2.3. Troubleshooting 5
3.	INSTRUCTIONS FOR USE
	3.1. Using the Heater 6 3.2. Using Accessories 6 3.3.1. Lighting 6 3.3.2. Ventilation 6 3.3.3. Safety Switch 6 3.3.4. Remote Switch 6 3.3.Remote Control 7 3.4. Control Panel Lock 8
4.	INSTRUCTIONS FOR INSTALLATION
	4.1. Installing the Control Panel114.2. Installing the Power Unit11
5.	OPTIONAL TIMECLOCK OPERATION
	5.1. Setting HeatPad for 24hr operation 12 5.5.1. Electrical Connections 12 5.5.2. Instructions for Installation 13 5.5.3. Power Unit Breaker Faults 13 5.5.4. Multidrive 17 5.2.Installing the Temperature Sensor 18 5.3.Resetting the Overheat Protector 18
6.	SPARE PARTS
7.	MAINTENANCE INSTRUCTIONS
8.	WARNINGS!
9	GUARANTEF 21

WARNINGS!

Do not smoke, use alcohol, or exercise in the sauna!

Do not exceed 30-minutes in the sauna at one time, as excessive exposure can be harmful to health. The sauna should not be used as an endurance test!

Persons with poor health should consult their physicians before using the sauna!

Avoid fire, do not place any combustible material over the sauna heater (towels, bathing suits, wooden bucket or dipper)!

Use only clean water on the stones - do not use pool or spa water, as chlorine gas can be produced and the heating elements can be damaged!

Keep away from the heater when it is hot. The stones and outer surface of the heater may burn your skin.

Do not pour too much water on the stones. The evaporating water is boiling hot.

Do not let young, handicapped or ill people bathe in the saune on their own.

Consult your dodcutor about health-related limitations of bathing.

Parents should keep their children away from the hot heater.

Consult your child welfare clinic about taking little babies to the sauna.

- Age?
- -Temperature of the sauna?
- -Time spent in the warm sauna?

Be very careful when moving in the sauna, as the platform and floors may be slippery.

Hyperthermia occurs when the internal temperature of the body reaches a level several degrees above the normal body temperatures of 98.6°F (37°C). The symptoms of hyperthermia include an increase in the internal temperature of the body, dizziness, lethargy, drowsiness, and fainting.

The effects of hyperthermia include:

- A) Failure to perceive heat
- B) Failure to recognize the need to exit the room
- C) Unawareness of impending hazard
- D) Fetal damage in pregnant women
- E) Physical inability to exit the room
- F) Unconsciousness

Warning - the use of alcohol, drugs or medication is capable of greatly increasing the risk of fatal hyperthermia!

HEATPAD SAUNA ENVIRONMENT CONTROLLER

GENERAL

The control unit consists of a control panel, a power unit and a sensor. See figure 1.

The control unit regulates the temperature in the sauna room based on information given by the sensor. The temperature sensor and the overheat protector are located in the sensor box. The temperature is sensed by an NTC thermistor, and there is a resettable overheat protector (see section 3.4.).

The control unit can be used to delay the start of the heater (timer delay). See figure 3.

TECHNICAL DATA

Control Panel:

- Temperature adjustment range 104 -194°F (40 - 90°C)
- Pre-setting time adjustment range 0 -12 h
- Lighting control, max. power 100W, 120V, 1Ph
- Fan control, max. power 100W, 120V,
 1Ph
- Dimensions: 3.4" x 1" x 4.4"
- 50' control cable length

Power Unit:

Supply voltage

HeatPad 10: 240V 1Ph, 208V 3Ph HeatPad 15: 240V 1Ph, 208V 3Ph

Max. load

HeatPad 10: 6kW 240V 1Ph

10kW 240V 1Ph (with dual circuits)

10kW 208V 3Ph

HeatPad 15: 8kW 240V 1Ph

15kW 240V 1Ph (with dual circuits)

15kW 208V 3Ph

Dimensions: 14.3" x 2.9" x 10.5"

Sensor:

- Temperature Sensor NTC thermistor 22kΩ/T=77°F (25°C)
- Resettable overheat protector
- Dimensions: 2.0" x 2.9" x 1.1"
- 50' sensor cable length




Figure 1. Control Unit Components

TROUBLESHOOTING

If an error occurs, the power to the heater will be cut off and the control panel will show an error message "E (number)", which helps troubleshooting the cause of the error. Table 1.

Note! The overheat protector can be reset by user. All other maintenance must be done by licensed professional maintenance personnel. Control unit should not be opened by unlicensed personnel.

If the heater does not heat properly, check heater grade from settings menu. See figure 3b.

	Description	Remedy / Solution
E1	Temperature sensor's measuring circuit broken.	Check the red and yellow wires to the temperature sensor and their connections (see figure 6) for faults.
E2	Temperature sensor's measuring circuit short-circuited.	Check the red and yellow wires to the temperature sensor and their connections (see figure 6) for faults.
E3	Overheat protector's measuring circuit broken.	Press the overheat protector's reset button (see section 3.4.). Check the blue and white wires to the temperature sensor and their connections (see figure 6) for faults.
E9	Connection failure in the system.	Switch the power off from the main switch (figure 1). Check the data cable, sensor cable/s and their connections. Switch the power on. Multidrive-system (see Section 3.2.4.): Switch the power off from all power units. Check the data cable, sensor cable/s, Multidrive cable and their connections

Table 1. Error messages. Note! The overheat protector can be reset by user. All other maintenance must be done by licensed professional maintenance personnel. No user-serviceable parts inside.

STATUS MESSAGES						
SAFE	Safety switch circuit is open	Remove the object from atop the safety switch.				
rESt	Pause time active	-				
rc on	Remote control activated					




Figure 2.

5

INSTRUCTIONS FOR USE

USING THE HEATER

WARNING! Before switching the heater on always check that there isn't anything on top of the heater or inside the given safety distance.

IMPORTANT! Before switching the heater on for the first time, change the right heater grade from the settings menu (SET 3). See figure 3b. See the right heater grade from the heater's type label, under "control unit grade settings".

The right heater grade must be chosen to pair the control unit and the heater. Right heater grade optimizes heater and ensures the best possible sauna experience.

When the heater starts, the top row of the display will show the set temperature and the bottom row will show the set on time for five seconds.

Start the heater by pressing the I/O button on the control panel.

When the desired temperature has been reached in the sauna room, the heating elements are automatically turned off. To maintain the desired temperature, the control unit will automatically turn the heating elements on and off in periods.

The heater will turn off when the set on time runs out, the I/O button is pressed or an error occurs.

The settings menu structure and changing the settings is shown in figure 3. Changing the temperature unit (Fahrenheit/Celsius) is shown in figure 3.a.

USING ACCESSORIES

Lighting and ventilation can be started and shut down separately from their own operating buttons.

LIGHTING

The lighting in the sauna room can be set up so that it can be controlled from the control panel. (Max 100W.)



Switch the lights on / off by pressing the button on the control panel

VENTILATION

If there is a fan installed in the sauna room, it can be connected to the control unit and be controlled from the control panel.



Start/Stop the fan by pressing the button on the control panel.

SAFETY SWITCH

Safety switch refers to e.g. SFE, a safety device installed above or integrated to the heater, preventing the heater from heating should any object (e.g. towel, piece of clothing) drop or be placed on the top of the heater and can cause a fire hazard.

The switch is connected to the control unit according to their manuals. See also figure 6 in this manual.

REMOTE SWITCH

To remotely control the heater's power input, the control unit can be equipped with an on/off remote switch (e.g. building automation or time clock). For more information, see 2.3.

REMOTE CONTROL

According to the product standard IEC/EN 60335-2-53 regulating electrical sauna heaters, a control unit can be used to remotely control the heater once the heater is equipped with a safety switch.

Using with a safety switch: The heater can be turned on remotely, if the safety switch circuit is closed. If the circuit is open, "SAFE" is displayed and the heater will not start.

Pause time: These features are limited by a pause time that prevents the heater from turning on if it has been less than 6-hours since the heater was last turned off. Trying to remotely turn the heater on during the pause time period (6-hours), text "rESt" is displayed. The heater can be remotely started after the pause time has elapsed and "rc" is displayed.

Memory for power failures: The control unit resumes operation, if the remote switch has remained in ON position.

Preset time: If the control unit is on preset delay time, it cannot be controlled with a remote switch. After the preset delay has passed and the heater is turned on, it can be turned off with a remote switch.

Operation: See page 12.

Wiring Schematic: ProHeat (pages 14). ClubHeat (pages 15).

CONTROL PANEL LOCK

	Press and hold the heater and light buttons for three seconds.
	-CL- is shown on the display. Panel lock can be activated only in standby mode. Panel lock also prevents remote start.
	Basic Mode (heater on) The top row shows the temperature in the sauna room. The bottom row shows the remaining on time. Both indicator lights glow.
MENU	Press the MENU button to open the settings menu.
	The display shows the sauna room temperature setting. Temperature indicator light blinks. • Change the setting to the desired temperature with the - and + buttons. The range is 104 - 194°F (40 - 90°C). The programmed temperature is stored in memory and will also apply when the heater is switched on next time.
MEALL	Press the MENU button to access the next setting.
	Remaining on-time Press the - and + buttons to adjust the remaining on-time. Example: The heater will be on for 40-minutes.
	 Set the timer delay in remaining on time mode: Press the + button to set the on time to maximu (1:00). Press the + button to enter the timer delay mode. The temperature indicator light switches off. Timer delay symbol blinks on the screen. Select the desired delay time using the - and + buttons. the time changes in 10-minute steps. Press and hold the button to make the time change faster. The adjustment range is from 10-minutes to 12-hours. Example: The heater will start after 10-minutes.
MENU	Exit by pressing the MENU button.
888 8 6	Basic Mode (timer delay running, heater off) The bottom row shows the remaining delay time. The decreases of time is shown until zero appears, after which the heater is switched on and will start to heat the sauna room.

ADDITIONAL SETTINGS




Table 3a. Settings menu structure, additional settings

^{*} Factory Setting




Table 3b. Changing the heater grade (See Section 2.1.)

* Factory Setting

INSTRUCTIONS FOR INSTALLATION

The electrical connections of the control unit may only be made by a licensed professional electrician and in accordance with the current regulations. When the installation of the control unit is complete, the person in charge of the installation must pass on to the user the Instructions for Installation and Use that come with the control unit and must give the user the necessary training for using the heater and the control unit.

INSTALLING THE CONTROL PANEL

The control panel is splashproof and has a low operating voltage. The panel can be installed in the dressing room, or in the living quarters. If the panel is installed in the sauna room, it must be installed at least 1.5' away from the heater and at a maximum height of 3' from the floor. Figure 4.

Conductor tubing (1-3/16") inside the wall structure allows you to thread the data cable hidden within the wall - otherwise the installation will have to be on the wall surface. We recommend you to install the control panel embedded in to the wall and far away from possible splashes.

INSTALLING THE POWER UNIT

Install the power unit to a wall outside the sauna room, in a dry place with an ambient temperature more than 32°F (0°C). See figure 5 for instructions on how to open the power unit cover and how to fix the unit to the wall.

Note! Do not embed the control unit into the wall, since this may cause excessive heating of the internal components of the unit and lead to damage. See figure 5.




Figure 4. Fastening the control panel

OPTIONAL TIMECLOCK OPERATION

HeatPad10/HeatPad15 control units can be installed with an optional time clock for customized on/off operation. See page 16 for optional time clock electrical connections.


SETTING HEATPAD FOR 24HR OPERATION

Step 1


ELECTRICAL CONNECTIONS

The heater and control unit may only be connected to the electrical network in accordance with the current regulations by a licensed professional electrician.

Figure 6 shows the electrical connections of the power unit. For more detailed installation instructions see The Instructions for Installation and Use of the selected heater model.



Step2



INSTRUCTIONS FOR INSTALLATION

The power unit of the HeatPad10 and HeatPad15 are controlled by the control panel.

- Control panel is connected to power unit via data cable.
- Only one control panel can be connected to the power unit.

Temperature Sensor:

 PTS-1015 is needed to operate HeatPad10 and HeatPad15. See section 3.3 for correct temperature sensor placement.

Two relay outputs (120V 1Ph):

 For driving a fan (max. 100W) and lighting (max. 100W).

Breakers on the electronics card (if a breaker has blown, see Section 3.2.3.):

- 40 mA breaker for electronic unit.
- Two 2.5 Ah breakers for relay outputs U1, U2, A1, A2.

Technical specifications:

Max. length of data cable: 80' (25m)

POWER UNIT BREAKER FAULTS

Replace a blown breaker by a new one with the same resistance. The replacement of the breakers in the power unit is shown in figure 6.

- If the breaker F2 for the electronic unit has blown, there is likely a fault in the power unit and it might need to be replaced. Service is required.
- If the breaker F3 has blown, there is a problem with lighting or fan. Check the wiring and functioning of lighting and fan.
- If the breaker F1 has blown, there is a problem with the heater's overheat protector circuit. In the heater, check the safety contactor circuit, overheat protector and their wiring.

NOTE! Only a qualified licensed electrician should replace the electronic card or fuse of the control unit, by following the necessary precautions!




Figure 5. Opening the power unit cover and mounting the unit to a wall




Figure 6.1 Electrical connections (HeatPad10/CX30-U1-U3 and HeatPad15/CX45-U1-U3) for ProHeat Sauna Heater models ➡ (P300/KIP30W1, P450/KIP45W1, P600/KIP60W1, P800/KIP80W1, P600-3/KIP60W3, and P800-3/KIP80W3)

CLUBHEAT SERIES SAUNA HEATERS ONLY




Figure 6.2 Electrical connections (HeatPad10/CX30-U1-U3 and HeatPad15/CX45-U1-U3) for ClubHeat Sauna Heater models 더 (C1000/K10G-U1, C1250/12.5G-U1, C1500/K15G-U1, C1000-3/K10G-U3, C1250-3/K12.5G-U3, and C1500-3/K15G-U3)




Figure 6.3 Optional Time Clock Electrical Connections (HeatPad10/CX30-U1-U3 and HeatPad15/CX45-U1-U3) for all ProHeat and ClubHeat sauna heater models.

MULTIDRIVE

Up to 8 power units can be connected in series so that they can share the same control panel. The connection principle is shown in figure 7.

- Connect the control panel to the first or last power unit in the chain.
- Connect the temperature sensor to the first power unit in the chain.
- Install a wire loop to the temperature sensor terminals in other power units. section 3.3. 4.

Install the sensor in the sauna room as described in

က

- Connect the power units together with Multidrive cables. വ.




Figure 7. Multidrive

INSTALLING THE TEMPERATURE SENSOR

Floor-mounted heaters (see figure 8)

 The temperature sensor is mounted on the wall above the heater, along the vertical center line running parallel to the sides of the heater, at a distance of 3-15/16" from ceiling.

Wall-mounted heaters (see figure 9)

The temperature sensor is wall-mounted above the heater, along the vertical center line running parallel to the sides of the heater, at a distance of 3-15/16" from the ceiling.

NOTE! The wire of the sensor can be extended with similar type of wire. Not exceeding 80' (25m).

RESETTING THE OVERHEAT PROTECTOR

The sensor box contains a temperature sensor and an overheat protect. An NTC thermistor senses the temperature, and the resettable overheat protector cuts off the heater power in a case of malfunction, after which the protect can be reset. See figure 11.

Note! The reason for the going off must be determined before the button is pressed.




Figure 9. The placement of the temperature sensor of the control unit in connection with wall-mounted heaters




Figure 8. The placement of the temperature sensor of the control unit in connection with floor-mounted heaters.




Figure 10. Sensor's minimumdistance from an air vent

Do not install the temperature sensor closer than 3' 3-3/8" to an air vent. This air flow near an air vent cools down the sensor, which gives inaccurate temperature readings to the control unit. As a result, the heater might overheat. See figure 10.





Figure 11. Reset button of the overheat protector

SPARE PARTS

Use only parts approved by the manufacturer!



1	Control panel
2	Data cable 50'
3	Temperature sensor, 50'
4	Circuit board
5a	Contactor 30 A (HeatPad10/CX30-U1-U3)
5b	Contactor 45 A (HeatPad15/CX45-U1-U3)
6	Multidrive cable 5' (optional)

MAINTENANCE INSTRUCTIONS

- 1. All service operations must be done by professional licensed maintenance personnel. Control unit should NOT be opened by unlicensed personnel.
- 2. Wipe dust and dirt from the power unit and the control panel with a damp cloth. DO NOT use running water!
- 3. Prevent any water from going inside the power unit at anytime.
- 4. The control panel is splashproof.

WARNINGS!

Do not smoke, use alcohol, or exercise in the sauna!

Do not exceed 30-minutes in the sauna at one time, as excessive exposure can be harmful to health. The sauna should not be used as an endurance test!

Persons with poor health should consult their physicians before using the sauna!

Avoid fire, do not place any combustible material over the sauna heater (towels, bathing suits, wooden bucket or dipper)!

Use only clean water on the stones - do not use pool or spa water, as chlorine gas can be produced and the heating elements can be damaged!

Keep away from the heater when it is hot. The stones and outer surface of the heater may burn your skin.

Do not pour too much water on the stones. The evaporating water is boiling hot.

Do not let young, handicapped or ill people bathe in the saune on their own.

Consult your dodcutor about health-related limitations of bathing.

Parents should keep their children away from the hot heater.

Consult your child welfare clinic about taking little babies to the sauna.

- Age?
- -Temperature of the sauna?
- -Time spent in the warm sauna?

Be very careful when moving in the sauna, as the platform and floors may be slippery.

Hyperthermia occurs when the internal temperature of the body reaches a level several degrees above the normal body temperatures of 98.6°F (37°C). The symptoms of hyperthermia include an increase in the internal temperature of the body, dizziness, lethargy, drowsiness, and fainting.

The effects of hyperthermia include:

- A) Failure to perceive heat
- B) Failure to recognize the need to exit the room
- C) Unawareness of impending hazard
- D) Fetal damage in pregnant women
- E) Physical inability to exit the room
- F) Unconsciousness

Warning - the use of alcohol, drugs or medication is capable of greatly increasing the risk of fatal hyperthermia!

GUARANTEE

This HOTASS SAUNA heater is guaranteed for one-year from date of purchase, and includes all heater parts such as heating elements, controls, contactors, etc.

This guarantee covers faults in manufacture and material only, and includes the exchange of new parts supplied by the manufacturer or importer, after the faulty part has been returned to same. The replacement of parts under warranty does not extend the warranty period beyond the original one-year.

The guarantee does not cover defects caused by normal wear and tear, defects caused by improper installation, poor maintenance, or failure to follow the manufacturer's instructions for installation, use and care, or alterations made to the sauna product.

This guarantee is void if the control is used improperly.

This guarantee does not cover delivery costs of the faulty part or costs of the person carrying out the repair in the field. If the control unit is returned to the manufacturer or the importer within five-years after date of purchase, the importer will provide free labor for repair, but will charge for parts if date of purchase is past one-year.

This guarantee will be void if installation and wiring is not carried out by a certified electrician or authorized and qualified service representative, who must sign below.

This guarantee will be void if information below is not filled out and returned within 15-days of purchase, and it applies only to original installation of product and to original purchaser.

SAUNA HEATER	
MODEL NUMBER	
DATE OF PURCHASE	
ORIGINAL OWNER	
ADDRESS	
PURCHASED FROM	
ELECTRICIAL CONTRACTOR	
MUST SIGN HERE	
DATE OF ELECTRICAL	
WIRING & HOOKUP	