














Computer Desk
CF6508



PART LIST


			
<p>Table Top 1 PC</p>	<p>Left Side Panel 1 PC</p>	<p>Right Side Panel 1 PC</p>	<p>Back Rail 1 PC</p>

HARDWARE LIST


 <p>Ø5/16"*1-1/2"</p>	 <p>Ø4mm*1-3/4"</p>	 <p>Ø5/16"*13mm</p>	 <p>Ø5/16"*16mm</p>	 <p>Ø8mm*1-1/8"</p>
<p>Hex Socket Head Bolt 9 PCS(Extra 1)</p>	<p>Flat Head Screw 3 PCS(Extra 1)</p>	<p>Spring Washer 9 PCS(Extra 1)</p>	<p>Flat Washer 9 PCS(Extra 1)</p>	<p>Wood Dowel 3 PCS(Extra 1)</p>
 <p>5mm</p> <p>Allen Wrench 1 PC</p>				







ADDITIONAL TOOLS(Not Provided)

Note:It is not recommended to use power tools during assembly.










Step 1. Carefully lay table top (part A) on a soft surface such as carpet as shown, and open drawers. Attach left side panel (part B) to table top (part A) using hex socket head bolts (part #1), spring washers (part #3), flat washers (part #4) and allen wrench (part #6). Attach back rail (part D) to left side panel (part B) using wood dowel (part #5), flat head screw (part #2) and Phillips head screwdriver.



- | | | |
|----|---|-----|
| #1 |  | x 4 |
| #3 |  | x 4 |
| #4 |  | x 4 |
| #6 |  | x 1 |
| #2 |  | x 1 |
| #5 |  | x 1 |

Step 2. Attach right side panel (part C) to table top (part A) and back rail (part D) using hex socket head bolts (part #1), spring washers (part #3), flat washers (part #4), allen wrench (part #6), wood dowel (part #5), flat head screw (part #2) and Phillips head screwdriver.



- | | | |
|----|---|-----|
| #1 |  | x 4 |
| #3 |  | x 4 |
| #4 |  | x 4 |
| #6 |  | x 1 |
| #2 |  | x 1 |
| #5 |  | x 1 |

Step 3. Carefully turn the computer desk upright.

