















CROSLEY
FURNITURE

















Sideboard
CF4212



PART LIST


<p>A</p> 	<p>B</p> 	<p>C</p> 	<p>D</p> 	<p>E</p> 
<p>Top Panel 1 PC</p>	<p>Bottom Panel 1 PC</p>	<p>Left Panel 1 PC</p>	<p>Partition Panel 1 PC</p>	<p>Right Panel 1 PC</p>
<p>F</p> 	<p>G</p> 	<p>H</p> 	<p>I</p> 	<p>J</p> 
<p>Left Door Panel 1 PC</p>	<p>Middle Door Panel 1 PC</p>	<p>Right Door Panel 1 PC</p>	<p>Cross Rail 1 PC</p>	<p>Left Adjustable Shelf 2 PCS</p>
<p>K</p> 	<p>L</p> 	<p>M</p> 		
<p>Right Adjustable Shelf 2 PCS</p>	<p>Small Back Panel 1 PC</p>	<p>Large Back Panel 1 PC</p>		

HARDWARE LIST

 #1 Cam Bolt 8 PCS (Extra 1)	 #2 Cam Lock 8 PCS (Extra 1)	 #3 Wood Dowel Ø8*30mm 9 PCS (Extra 1)	 #4 Round Head Screw 12*Ø3*D6mm 8 PCS (Extra 1)	 #5 Round Head Bolt 3/4**Ø5/32**D9 3 PCS (Extra 1)
 #6 Flat Head Screw 1**Ø3.5*D8mm 2 PCS	 #7 Bolt 2**Ø1/4**D11mm 6 PCS (Extra 1)	 #8 Barrel Nut 6 PCS	 #9 Screw Ø12*7*D6mm 24 PCS (Extra 1)	 #10 Small Magnet 2 PCS
 #11 Large Magnet 2 PCS	 #12 Knob 3 PCS	 #13 Shelf Holder 16 PCS	 #14 Adjustable Leveler 4 PCS	 #15 Allen Wrench 1 PC
 #16 Safety Strap Kit 1 PC				

ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver


Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Step 1. Attach magnets (parts #10 & #11) to cross rail (part I) and bottom panel (part B) using round head screws (part #4) and phillips head screwdriver. Attach knobs (part #12) to door panels (parts F, G & H) using round head bolts (part #5) and phillips head screwdriver.




Step 2. Attach cam bolts (part #1) to panels (parts A, C & E) using phillips head screwdriver.

NOTE: Do not overtighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.




Step 3. Attach cross rail (part I) to partition panel (part D) using wood dowel (part #3), flat head screw (part #6) and phillips head screwdriver. Attach panels (parts C & E) to cross rail (part I) using wood dowels (part #3) and cam locks (part #2).

NOTE: Cam locks must rotate a full 180°. See pictured insert.




Step 4. Attach bottom panel (part B) to assembled unit (parts C, D & E) using wood dowels (part #3), bolts (part #7), barrel nuts (part #8) and allen wrench (part #15). Attach adjustable levelers (part #14) to bottom panel (part B).




Step 5. Carefully turn unit upright. Attach top panel (part A) to assembled unit (parts C, D, E & I) using cam locks (part #2), flat head screw (part #6) and phillips head screwdriver.


NOTE: Cam locks must rotate a full 180°. See pictured insert.



Step 6. Attach back panels (parts L & M) to assembled unit (parts A, B, C, D & E) using screws (part #9) and phillips head screwdriver.



Step 7. Place shelf holders (part #13) into desired position and then slide adjustable shelves (parts J & K) into place.




#13  x 16







Step 8. Attach door panels (parts F, G & H) by placing bottom pin hinge (pre-installed in door) in the pre-drilled hole of bottom panel (part B). Then depress the top spring-loaded pin hinge so it can be placed in the pre-drilled hole of cross rail (part I).

NOTE: Be sure top and bottom pin hinges are fully extended to secure doors in place.

NOTE: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.

Important: Safety strap kit (part #16) must be installed to prevent tipping, damage and /or injury.




#16 	A 	B 	C  D8*3/4"	D  D8*1-1/2"	E 
Safety Strap Kit 1 PC	Wall Anchor 1 PC	Washer 2 PCS	Short Screw 1 PC	Long Screw 1 PC	Safety Wall Strap 1 PC

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) through washer (B) and safety wall strap (E) and attach to large back panel (part M) using phillips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in large back panel (part M) where the safety wall strap (E) is attached. Tap wall anchor (A) into the hole.
3. Insert long screw (D) through washer (B) and safety wall strap (E) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



▲ WARNING	
	Children have died from furniture tipover. To reduce the risk of furniture tipover:
	· ALWAYS install tipover restraint provided.
	· For use with televisions weighing 50lbs(23kg) or less. Use with heavier televisions may result in instability causing tip-over resulting in death or serious injury.
	· NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
	· NEVER open more than one drawer at a time.
	· Place heaviest items in the lowest drawers.
	<i>This is a permanent label. Do not remove!</i>