

















Stainless Steel Chair  
CO1020



# PARTS LIST

<div data-bbox="119 212 151 257" style="border: 1px solid black; padding: 2px;">1</div> 	<div data-bbox="391 212 422 257" style="border: 1px solid black; padding: 2px;">2</div> 	<div data-bbox="670 212 702 257" style="border: 1px solid black; padding: 2px;">3</div> 	<div data-bbox="949 212 981 257" style="border: 1px solid black; padding: 2px;">4</div> 
<p>Back and Seat 1 PC</p>	<p>Left Support Leg 1 PC</p>	<p>Right Support Leg 1 PC</p>	<p>Leg Connector 1 PC</p>


# HARDWARE

<div data-bbox="111 728 151 772" style="border: 1px solid black; padding: 2px;">A</div>  <p>M6X40mm</p>	<div data-bbox="391 728 430 772" style="border: 1px solid black; padding: 2px;">B</div> 	<div data-bbox="670 728 710 772" style="border: 1px solid black; padding: 2px;">C</div> 	<div data-bbox="949 728 989 772" style="border: 1px solid black; padding: 2px;">D</div> 	<div data-bbox="1228 728 1268 772" style="border: 1px solid black; padding: 2px;">E</div> 
<p>Bolt 4 PCS</p>	<p>Nut 4 PCS</p>	<p>Flat Washer 4 PCS</p>	<p>Wrench 1 PC</p>	<p>Allen Key 1 PC</p>
<div data-bbox="111 1108 151 1153" style="border: 1px solid black; padding: 2px;">F</div> 	<div data-bbox="391 1108 430 1153" style="border: 1px solid black; padding: 2px;">G</div> 	<div data-bbox="670 1108 710 1153" style="border: 1px solid black; padding: 2px;">H</div> 	<div data-bbox="949 1108 989 1153" style="border: 1px solid black; padding: 2px;">I</div> 	
<p>Foot Cap 2 PCS</p>	<p>Plastic Washer 2 PCS</p>	<p>Cross Head Bolt 2 PCS</p>	<p>Round Plastic Washer 4 PCS</p>	


**IMPORTANT NOTE: WE RECOMMEND TWO PEOPLE WORK TOGETHER TO ASSEMBLE THE CHAIR**

**ADDITIONAL TOOLS (Not Provided)**


**Note: It is not recommended to use power tools during assembly.**





Step 1. Attach left support leg (part #2) and right support leg (part #3) using leg connector (part #4).




Step 2. Attach foot caps (part F) into the pre-drilled holes on the bottom of the support legs (parts #2&3) and leg connector (part #4) using cross head bolts (part H) and Phillips head screwdriver.




F  X 2  
H  X 2








**Step 3. IMPORTANT:** Only attach support legs (parts #2&3) to SEAT portion of back and seat (part #1) where shown. Do not attach support legs (parts #2&3) to BACK portion of back and seat (part #1) until instructed!

Attach seat (part #1) to support legs (parts #2&3) using bolts (part A), flat washers (part C), Round Plastic Washer (part I), nuts (part B), wrench (part D) and allen key (part E). Note: Please make sure support legs (parts #2&3) are properly aligned and flush with the bottom rail of the seat (No gaps) before fully tightening all bolts. Hold nuts (part B) in place with wrench (part D) and turn bolts (part A) with allen key (part E) to tighten.



Step 4. NOTE: It may be necessary to apply pressure and force the back and seat (part #1) into position. Attach support legs (parts #2&3) to back (part #1) using bolts (part A), flat washers (part C) and Round Plastic Washer (part I), plastic washers (part G), nuts (part B), wrench (part D) and allen key (part E). Please fully tighten all bolts.



- |   |   |     |
|---|---|-----|
| A |  | X 2 |
| C |  | X 2 |
| B |  | X 2 |
| G |  | X 2 |
| D |  | X 1 |
| E |  | X 1 |
| I |  | X 2 |